

USER MANUAL

KPM302

KPM303

TK302

TK303

CUSTOM®

CUSTOM S.p.A.
Via Berettine 2/B
43010 Fontevivo (PARMA) - Italy
Tel. : +39 0521-680111
Fax : +39 0521-610701
http://www.custom.biz

Customer Service Department:
Email : support@custom.it

© 2017 CUSTOM S.p.A. – Italy.

All rights reserved. Total or partial reproduction of this manual in whatever form, whether by printed or electronic means, is forbidden. While guaranteeing that the information contained in it has been carefully checked, CUSTOM S.p.A. and other entities utilized in the realization of this manual bear no responsibility for how the manual is used. Information regarding any errors found in it or suggestions on how it could be improved are appreciated. Since products are subject to continuous check and improvement, CUSTOM S.p.A. reserves the right to make changes in information contained in this manual without prior notification.

The pre-installed multimedia contents are protected from Copyright CUSTOM S.p.A. Other company and product names mentioned herein may be trademarks of their respective companies. Mention of third-party products is for informational purposes only and constitutes neither an endorsement nor a recommendation. CUSTOM S.p.A. assumes no responsibility with regard to the performance or use of these products.

THE IMAGES USED IN THIS MANUAL ARE USED AS AN ILLUSTRATIVE EXAMPLES. THEY COULDN'T REPRODUCE THE DESCRIBED MODEL FAITHFULLY.

**UNLESS OTHERWISE SPECIFIED,
THE INFORMATION GIVEN IN THIS
MANUAL
ARE REFERRED TO ALL MODELS
IN PRODUCTION AT THE ISSUE
DATE OF THIS DOCUMENT.**

GENERAL INSTRUCTIONS

CUSTOM S.p.A. declines all responsibility for accidents or damage to persons or property occurring as a result of tampering, structural or functional modifications, unsuitable or incorrect installations, environments not in keeping with the equipment's protection degree or with the required temperature and humidity conditions, failure to carry out maintenance and periodical inspections and poor repair work.

GENERAL SAFETY INFORMATION

Your attention is drawn to the following actions that could compromise the characteristics of the product:

- Read and retain the instructions which follow.
- Follow all indications and instructions given on the device.
- Make sure that the surface on which the device rests is stable. If it is not, the device could fall, seriously damaging it.
- Make sure that the device rests on a hard (non-padded) surface and that there is sufficient ventilation.
- Do not fix indissolubly the device or its accessories such as power supplies unless specifically provided in this manual.
- When positioning the device, make sure cables do not get damaged.
- [Only OEM equipment] The equipment must be installed in a kiosk or system that provides mechanical, electrical and fire protection.
- The mains power supply must comply with the rules in force in the Country where you intend to install the equipment.
- Make sure that there is an easily-accessible outlet with a capacity of no less than 10A closely to where the device is to be installed.
- Make sure the power cable provided with the appliance, or that you intend to use is suitable with the wall socket available in the system.
- Make sure the electrical system that supplies power to the device is equipped with a ground wire and is protected by a differential switch.
- Before any type of work is done on the machine, disconnect the power supply.
- Use the type of electrical power supply indicated on the device label.
- These devices are intended to be powered by a separately certified power module having an SELV, non-energy hazardous output. (IEC60950-1 second edition).
- [Only POS equipment] The energy to the equipment must be provided by power supply approved by CUSTOM S.p.A.
- Take care the operating temperature range of equipment and its ancillary components.
- Do not block the ventilation openings.
- Do not insert objects inside the device as this could cause short-circuiting or damage components that could jeopardize printer functioning.
- Do not carry out repairs on the device yourself, except for the normal maintenance operations given in the user manual.
- The equipment must be accessible on these components only to trained, authorized personnel.
- Periodically perform scheduled maintenance on the device to avoid dirt build-up that could compromise the correct, safe operation of the unit.
- Do not touch the head heating line with bare hands or metal objects. Do not perform any operation inside the printer immediately after printing because the head and motor tend to become very hot.
- Use consumables approved by CUSTOM S.p.A.



THE CE MARK AFFIXED TO THE PRODUCT CERTIFY THAT THE PRODUCT SATISFIES THE BASIC SAFETY REQUIREMENTS.

The device is in conformity with the essential Electromagnetic Compatibility and Electric Safety requirements laid down in Directives 2006/95/CE and 2004/108/CE inasmuch as it was designed in conformity with the provisions laid down in the following Standards:

- EN 55022 Class B (*Limits and methods of measurements of radio disturbance characteristics of Information Technology Equipment*)
- EN 55024 (*Information Technology Equipment – Immunity characteristics – Limits and methods of measurement*)
- EN 60950-1 (*Safety of information equipment including electrical business equipment*)

The device is in conformity with the essential requirements laid down in Directives 1999/05/CE about devices equipped with intentional radiators. The Declaration of Conformity and other available certifications can be request to support@custom.it please providing the correct part number shown on product label or in the invoice.



GUIDELINES FOR
THE DISPOSAL OF
THE PRODUCT

The crossed-out rubbish bin logo means that used electrical and electronic products shall NOT be mixed with unsorted municipal waste. For more detailed information about recycling of this product, refer to the instructions of your country for the disposal of these products.

- Do not dispose of this equipment as miscellaneous solid municipal waste, but arrange to have it collected separately.
- The re-use or correct recycling of the electronic and electrical equipment (EEE) is important in order to protect the environment and the wellbeing of humans.
- In accordance with European Directive WEEE 2002/96/EC, special collection points are available to which to deliver waste electrical and electronic equipment and the equipment can also be handed over to a distributor at the moment of purchasing a new equivalent type.
- The public administration and producers of electrical and electronic equipment are involved in facilitating the processes of the re-use and recovery of waste electrical and electronic equipment through the organisation of collection activities and the use of appropriate planning arrangements.
- Unauthorised disposal of waste electrical and electronic equipment is punishable by law with the appropriate penalties.



The format used for this manual improves use of natural resources reducing the quantity of necessary paper to print this copy.

MANUAL

For details on the commands,
refer to the manual with code **77200000030600**

TABLE OF CONTENTS

1	INTRODUCTION	11
2	IDENTIFICATION OF THE MODELS	13
3	DESCRIPTION	15
3.1	Box contents	15
3.2	Device components: external views	19
3.3	Device components: connectors view	28
3.4	Device components: internal view	29
3.5	Device labels	30
3.6	Key functions: power up	31
3.7	Key functions: standby	32
3.8	Status LED flashes	33
3.9	Triple feeder LED flashes	34
3.10	Messages on display	35
4	INSTALLATION	37
4.1	Fixing brackets	37
4.2	Fixing slots	41
4.3	BURSTER configuration	43
4.4	CUT&DROP configuration	46
4.5	Connections	50
4.6	Pinout	52
4.7	Driver and SDK	55
5	OPERATION	57
5.1	Adjusting paper width	57
5.2	Adjusting the alignment sensors	58
5.3	Switch device on	60
5.4	Loading the paper roll	63
5.5	Issuing ticket	67


6 CONFIGURATION	85
6.1 Configuration mode	85
6.2 Setup report	88
6.3 Printer status	90
6.4 Printer parameters	91
6.5 Ethernet parameters	96
6.6 Hexadecimal dump	97
6.7 Calendar clock	98
7 MAINTENANCE	101
7.1 Printer paper jam	101
7.2 Triple feeder paper jam	103
7.3 Planning of cleaning operations	104
7.4 Cleaning	105
7.5 Upgrade firmware	110
8 SPECIFICATION	113
8.1 Hardware specification	113
8.2 Character specifications	118
8.3 Specifications for RFID reader/writer	119
8.4 Specifications for barcode reader	120
8.5 Device dimensions	121
8.6 Device dimensions with CUT&HOLD kit	136
8.7 Device dimensions with paper roll holder	137
8.8 Device dimensions with height reduction kit	138
8.9 Device dimensions with power supply container	139
8.10 Device dimensions with metallic ticket tray	140
8.11 Device dimensions with plastic ticket tray	141
8.12 Power supply dimensions	142
8.13 Paper specification	143
8.14 Character sets in CUSTOM/POS emulation	151
8.15 Character sets in SVELTA emulation	158
9 CONSUMABLES	159
10 ACCESSORIES	161
10.1 Paper roll holder	166
10.2 Wirings kit with low paper sensor boards	167
11 ALIGNMENT	169
11.1 Enable alignment	170
11.2 Calibration	175
11.3 Alignment parameters	178
11.4 Printing area	182
12 TECHNICAL SERVICE	183

13 ADVANCED FUNCTIONS	185
13.1 File sharing	185
13.2 Embedded Web Server.....	186
13.3 Embedded Web Server : access	187
13.4 Embedded Web Server: functions	189
13.5 Locator	191
13.6 Drivers installation	192
13.7 Logos management	193
13.8 Fonts management.....	195
13.9 Setup	197



1 INTRODUCTION

This document is divided into sections and chapters. Each chapter can be reached by the index at the beginning of this document. The index can be reached by the button on each page as shown in the diagram below.







2 IDENTIFICATION OF THE MODELS

NOMENCLATURE	DESCRIPTION
KPM302 STD	KPM302 base configuration (OEM model with 200 dpi print head)
KPM303 STD	KPM303 base configuration (OEM model with 300 dpi print head)
KPM302 EJ	KPM302 with ejector group
KPM303 EJ	KPM303 with ejector group
KPM302 vSEL	KPM302 with selector group for vertical fixing
KPM303 vSEL	KPM303 with selector group for vertical fixing
KPM302 TF	KPM302 with triple feeder
KPM302 TF-EJ	KPM302 with triple feeder and ejector group
KPM302 TF-vSEL	KPM302 with triple feeder and selector group for horizontal fixing
KPM302 TF-hSEL	KPM302 with triple feeder and selector group for horizontal fixing
TK302 STD	TK302 base configuration (TKT model with 200 dpi print head)
TK303 STD	TK303 base configuration (TKT model with 300 dpi print head)
TK302 TF	TK302 with triple feeder



3 DESCRIPTION


3.1 Box contents

Remove the device from its carton being careful not to damage the packing material so that it may be re-used if the device is to be transported in the future.

Make sure that all the components illustrated below are present and that there are no signs of damage. If there are, contact Customer Service.

KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL


1. Installation instruction sheet
2. Power supply cable
3. Spacer for paper width < 40 mm
(only for KPM302 STD,
KPM303 STD)
4. Additional fixing brackets
5. CUT&DROP configuration
kit (only for KPM302 STD,
KPM303 STD)
6. BURSTER configuration kit
(only for KPM302 STD,
KPM303 STD)
7. Ruler
8. Device






KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL

1. Installation instructions sheet
2. Power supply cable
3. CUT&DROP configuration kit
(only for KPM302 TF)
4. BURSTER configuration kit
(only for KPM302 TF)
5. Ruler
6. Device



TK302 STD, TK303 STD


1. Power supply
2. Short guide
3. Power supply cable 220V
4. USB cable
5. Serial cable
6. Ruler
7. Spacer for paper width < 40 mm
8. Device





TK302 TF

1. Power supply
2. Short guide
3. USB cable
4. Power supply cable 220V
5. Serial cable
6. Ruler
7. Device




- Open the device packaging.
- Take out the device.
- Take out the rest of the content.
- Keep the box, trays and packing materials in the event the device must be transported/shipped in the future.

3.2 Device components: external views

KPM302 STD, KPM303 STD


- | | |
|--|-------------------|
| 1. Printing head group | 7. Paper input |
| 2. Device chassis | 8. S2 key |
| 3. External connector for low paper sensor | 9. Status LED |
| 4. Paper out | 10. S1 key |
| 5. Front cover | 11. FORM FEED key |
| 6. Opening lever for upper cover | 12. LINE FEED key |





KPM302 EJ, KPM303 EJ


- | | |
|--|-------------------|
| 1. Printing head group | 7. Paper input |
| 2. Device chassis | 8. S2 key |
| 3. External low paper sensor connector | 9. Status LED |
| 4. Paper out | 10. S1 key |
| 5. Front cover with ejector group | 11. FORM FEED key |
| 6. Opening lever for upper cover | 12. LINE FEED key |





KPM302 vSEL, KPM303 vSEL


- | | |
|--|----------------------------------|
| 1. Printing head group | 8. Opening lever for upper cover |
| 2. Device chassis | 9. Paper input |
| 3. External low paper sensor connector | 10. S2 key |
| 4. Paper out | 11. Status LED |
| 5. Sensor for tilting slide position | 12. S1 key |
| 6. Tilting slide | 13. FORM FEED key |
| 7. Front cover with selector group | 14. LINE FEED key |






KPM302 TF

- | | |
|----------------------------------|-------------------------------|
| 1. Device chassis | 9. Triple feeder |
| 2. Printing head group | 10. Paper input feeder 1 |
| 3. Release lever for upper cover | 11. Paper input feeder 2 |
| 4. LINE FEED key | 12. Paper input feeder 3 |
| 5. FORM FEED key | 13. Triple feeder LED (green) |
| 6. S1 key | 14. Triple feeder LED (red) |
| 7. S2 key | 15. Paper out |
| 8. Status LED | 16. Front cover |



KPM302 TF-EJ


1. Device chassis
2. Printing head group
3. Release lever for upper cover
4. LINE FEED key
5. FORM FEED key
6. S1 key
7. S2 key
8. Status LED
9. Triple feeder
10. Paper input feeder 1
11. Paper input feeder 2
12. Paper input feeder 3
13. Triple feeder LED (green)
14. Triple feeder LED (red)
15. Front cover with ejector group
16. Paper out






KPM302 TF-vSEL

- | | |
|----------------------------------|---------------------------------------|
| 1. Device chassis | 10. Paper input feeder 1 |
| 2. Printing head group | 11. Paper input feeder 2 |
| 3. Release lever for upper cover | 12. Paper input feeder 3 |
| 4. LINE FEED key | 13. Triple feeder LED (green) |
| 5. FORM FEED key | 14. Triple feeder LED (red) |
| 6. S1 key | 15. Front cover with selector group |
| 7. S2 key | 16. Paper out |
| 8. Status LED | 17. Tilting slide |
| 9. Triple feeder | 18. Sensor for tilting slide position |



KPM302 TF-hSEL


- | | |
|----------------------------------|---------------------------------------|
| 1. Device chassis | 10. Paper input feeder 1 |
| 2. Printing head group | 11. Paper input feeder 2 |
| 3. Release lever for upper cover | 12. Paper input feeder 3 |
| 4. LINE FEED key | 13. Triple feeder LED (green) |
| 5. FORM FEED key | 14. Triple feeder LED (red) |
| 6. S1 key | 15. Frontal cover with selector group |
| 7. S2 key | 16. Paper out |
| 8. Status LED | 17. Tilting slide |
| 9. Triple feeder | 18. Sensor for tilting slide position |





TK302 STD, TK303 STD


1. Paper out
2. FORM FEED key
3. LINE FEED key
4. Display
5. Captive knob for connector cover opening
6. Connectors cover
7. Internal printer (see previous pages)
8. Paper input





TK302 TE


1. Paper out
2. FORM FEED key
3. LINE FEED key
4. Display
5. Internal printer with triple feeder (see previous pages)
6. Connectors cover
7. Captive knob for connector cover opening





3.3 Device components: connectors view

1. Cover for external low paper sensor connectors (for models with triple feeder)
2. USB port
3. RS232 serial port
4. ETHERNET port
5. Slot for SD/MMC card
6. Power supply port




NOTE: For ease of reference, for some models is represented only the internal printer group without external plastic chassis or triple feeder.



3.4 Device components: internal view

1. Paper out presence
2. Opening/closing front cover sensor
3. Cutter position sensor
4. Unlocking button for mobile paper guide
5. Mobile sensors for alignment notch
6. Head temperature sensor
7. Sensor of paper presence
8. Opening/closing upper cover sensor




NOTE: For ease of reference, for some models is represented only the standard model of internal printer group without external plastic chassis or triple feeder.




3.5 Device labels

PC = Product code (14 digits)
SN = Serial number
HW = Hardware release





3.6 Key functions: power up




NOTE:

During power-up, do not press the S2 key because the device enters in a test modality that becomes unusable by keys; if this event occurs then turn off the device and turn on without pressing any key.



3.7 Key functions: standby


KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL



NOTE:

(*) Only with alignment enabled

TK302 STD, TK303 STD, TK302 TF





3.8 Status LED flashes

The status LED indicates hardware status of device. Given in the table below are the various LED signals and the corresponding device status.

STATUS LED		DESCRIPTION
-		OFF DEVICE OFF
GREEN		ON DEVICE ON: NO ERROR
GREEN COMMUNICATION STATUS		$x 1$ RECEIVE DATA
		$x 2$ RECEPTION ERRORS (PARITY, FRAME ERROR, OVERRUN ERROR)
		$x 3$ COMMAND NOT RECOGNIZED
		$x 4$ COMMAND RECEPTION TIME OUT
YELLOW RECOVERABLE ERROR		$x 2$ PRINthead OVERHEATED
		$x 3$ PAPER END
		$x 4$ PAPER JAM
		$x 5$ POWER SUPPLY VOLTAGE INCORRECT
RED UNRECOVERABLE ERROR		$x 6$ COVER OPEN
		$3x$ RAM ERROR
		$4x$ EEPROM ERROR
		$5x$ CUTTER ERROR
		$6x$ FRONT COVER OPEN



3.9 Triple feeder LED flashes

KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF

The LED panel of triple feeder is comprised of two LED (one of green colour and one of red colour) for each of the three paper input feeder.

The LED indicate the triple feeder status and the paper status. Given in the table below are the various LED signals and the corresponding triple feeder status.

STATUS LED		DESCRIPTION
RED PAPER END WARNING		OFF PAPER PRESENCE
		ON LOW PAPER
GREEN TRIPLE FEEDER STATUS		OFF NO PAPER OR PAPER IN PARKING SPACE ⁽¹⁾
		ON PAPER LOADED
		PAPER END DURING PRINTING
		PAPER JAM

NOTE:

(1) The paper is in “parking space” when it is present on entrance of feeder but it is not loaded into the printer.



3.10 Messages on display

The display indicates the hardware status of device. Given in table below are the various display messages and the corresponding device status.

TK302 STD, TK303 STD, TK302 TF

PRINTER READY 01/01/17 12:00:00 Device ON: no error	RECEIVING DATA SPOOLING..... Receive data
RS232 RX ERROR CHECK RS232 SETTINGS Reception errors (parity, frame error, overrun error)	COMMAND ERROR COMMAND NOT FOUND Command not recognized
COMMAND ERROR COMMAND NOT FINISH Command reception time out	PRINthead OVERTEMP WAIT COOLING..... Heading over temperature
END PAPER PLEASE INSERT PAPER Paper end	PAPER JAM CLEAR PAPER PATH Paper jam
POWER VOLTAGE ERROR CHECK POWER SUPPLIER Power supply voltage incorrect	COVER ERROR CLOSE COVERS Cover open
RAM ERROR POWER ON AGAIN RAM error	EEPROM ERROR POWER ON AGAIN EEPROM error
CUTTER ERROR OPEN COVER AND CLEAR Cutter error	CUTTER ERROR CUTTER COVER OPEN! Cutter cover open
PRINT TICKET ERROR! CHECK TICKETS PATH Notch alignment error	





4 INSTALLATION


4.1 Fixing brackets

**KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL**


The device includes a kit for the assembly of two additional fixing brackets (see following figure).

The kit contains:

1. Two fixing brackets;
2. No.4 fixing screws.




For the assembly procedure, proceed as follows:





The following figures show the device overall dimensions with additional brackets.





KPM302 STD, KPM303 STD



NOTE: All the dimensions shown in figures are in millimetres.




KPM302 STD, KPM303 STD (CUT&DROP configuration)



NOTE: All the dimensions shown in figures are in millimetres.



KPM302 STD, KPM303 STD (BURSTER configuration)



NOTE: All the dimensions shown in figures are in millimetres.




4.2 Fixing slots

TK302 STD, TK303 STD, TK302 TF

The device is provided with two slots for the mounting of the machine on desk.

The slots are placed at the bottom of the machine (see following figure)



SECTION D-D



The height A shown in the previous figure varies according to the accessory mounted to the device (see chapter 10).

Arrange the desk with two fixing pins according to measures shown in the previous page and the values of the height A listed in the table below.

CONFIGURATION	HEIGHT
Device	12.5 mm
Device with paper roll holder (cod.974BA010000312)	16 mm
Device with plastic ticket tray (cod.976BD010000001)	18 mm
Device with metallic ticket tray (cod.976BB010000003)	14.5 mm


4.3 BURSTER configuration

KPM302 STD, KPM303 STD, KPM302 TF


The device includes a kit for BURSTER configuration (see following figure).

The kit contains:

1. Upper paper out feed mouth.




For the assembly procedure, proceed as follows:






2



Unscrew the fixing screws and remove the upper paper mouth
for the standard configuration.


3



Unscrew the fixing screw and remove the light guide from the paper mouth for the standard configuration.
Using the same screw, fix the same light guide to the paper mouth for the BURSTER configuration.




4



Unscrew the fixing pins and take off the fixed blade and the spring.

5



Fix the paper mouth group for the BURSTER configuration
by using the screws previously removed.

NOTE:

For ease of reference, for model with triple feeder is represented only the printer group without triple feeder.


4.4 CUT&DROP configuration

KPM302 STD, KPM303 STD, KPM302 TF


The device includes a kit for the CUT&DROP configuration (see following figure).


The kit contains:

1. Label
2. Lower paper out feed mouth.




For the assembly procedure, proceed as follows:



2


Unscrew the fixing screws and remove the upper paper mouth for the standard configuration.

3

Using a clamp, remove the precut sheet metal on the upper device cover.




4




Fix the upper paper group for the standard configuration in the upper holes on the cover using the screws previously removed.


5



Unscrew the two fixing screws on the front cover and take off the lower paper mouth of the standard configuration.

6

Fix the lower paper mouth for the CUT&DROP configuration
by using the screws previously removed.

7

Close the upper cover and paste the
label (supplied with the CUT&DROP kit) on the front cover.


NOTE:

For ease of reference, for model with triple feeder is represented only the printer group without triple feeder.

4.5 Connections

The following figures show the possible connections for devices.

**KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL**




ATTENTION: In some using conditions, we recommend the installation of a ferrite core on the power supply cable.

NOTES:

When the RS232 and USB communication cables are connected to the printer at the same time, communication takes place via the USB port.

For ease of reference, for some models is represented only the printer group without the triple feeder.

TK302 STD, TK303 STD, TK302 TF



ATTENTION: In some using conditions, we recommend the installation of a ferrite core on the power supply cable.

NOTES:

When the RS232 and USB communication cables are connected to the printer at the same time, communication takes place via the USB port.

For ease of reference, for some models is represented only the printer group without the triple feeder.



4.6 Pinout



POWER SUPPLY

Male Molex connector vertical (no. 39-30-0060)

J26	1	+24 Vdc
	2	+24 Vdc
	3	+24 Vdc
	4	GND
	5	GND
	6	GND


ATTENTION:

Respect power supply polarity.


NOTE:

Power supply cable

The following figure shows the connector pinout of power supply cable:




PIN	Cable color	Signal
1	Red	+24V
2	not connected	+24V
3	Red	+24V
4	Black	GND
5	not connected	GND
6	Black	GND



USB INTERFACE

Female USB type B connector

J13	1	USB-VBUS (out)
	2	PD -0
	3	PD +0
	4	GND



RS232 SERIAL INTERFACE

Female DB9 connector


J1	Pin Number	Function
	1	DCD
	2	TX During transmission, takes the values -VRS232 and + VRS232 depending on data
	3	RX During reception, takes the values -VRS232 and +VRS232 depending on data
	4	DSR
	5	GND
	6	DTR When +VRS232, device is power on
	7	CTS
	8	RTS When +VRS232, device is ready to receive data
	9	n.c.

NOTES:


Given the presence of the RS232 standard, logic value "0" corresponds to the voltage value +VRS232 (voltage value between +3Vdc and +15Vdc) and logic value "1" corresponds to the voltage value -VRS232 (voltage value between -3Vdc and -15Vdc).

DEVICE > PC connection

The following picture shows an example of connection between the device and a personal computer using a 9 pin RS232 serial connector:



When use a serial cable, we recommend the installation of a ferrite core on the power supply cable.



ETHERNET INTERFACE

Female RJ45 connector

J16	1	TPOUT +
	2	TPOUT -
	3	TPIN +
	4	GND
	5	GND
	6	TPIN -
	7	n.c
	8	n.c
	9	+3.3 V
	10	LED-LAN
	11	+3.3 V
	12	LED-LNK
	13	Shield
	14	Shield

NOTES:

The functionality of two LED are specified in following tables:

- For 10Base-T connection:

LED	FUNCTION
LED-LNK	Link (yellow color): the LED lights up when a connection is active
LED-LAN	Rx/Tx: (green color): the LED lights up when occurs a data reception or transmission

- For 10/100Base-TX connection:

LED	FUNCTION
LED-LNK	The LED light (yellow color) on when a connection is active and flashes when occurs a data reception or transmission
LED-LAN	The LED light (green color) on when occurs a 100 Mbit connection and off when occurs a 10 Mbit connection

The device automatically recognizes the type of connection (cross or pin-to-pin).

The pinout shown in table represents the input signals to component J16 before the isolation voltage transformer (through-hole pin).



4.7 Driver and SDK

The drivers are available for the following operating system:

OPERATING SYSTEM	DESCRIPTION	INSTALLATION PROCEDURE
Windows	Driver for Windows XP	
	Driver for Windows VISTA (32/64bit)	
	Driver for Windows 7 (32/64bit)	
	Driver for Windows 8 (32/64bit)	From the START menu, press Run and type-in the path where the SW was saved on your PC, then click OK. Follow the instructions that appear on the screen to install the driver.
	Driver for Windows 8.1 (32/64bit)	
	Driver for Windows 10 (32/64bit)	
Linux	Driver for OPOS	
	Driver for Linux (32/64bit)	Follow the instruction get back on the README.TXT file. You can find it in the software package downloaded in advance.
Android	SDK for CustomAndroidAPI	Extract the zipped folder to the destination path desired. Follow the instructions present in the software package that you downloaded on how to install and use the SDK.
iOS	SDK for CustomiOSApi	Extract the zipped folder to the destination path desired. Follow the instructions present in the software package that you downloaded on how to install and use the SDK.

NOTE:

All drivers and SDK can be found in the DOWNLOAD section of the web site www.custom.biz.




5 OPERATION


5.1 Adjusting paper width

KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, TK302 STD, TK303 STD

Paper width may be adjusted from 40 mm to 82.5 mm by pressing the unlocking button and moving the adjustable paper guide as shown in the figure.



To manage paper width from 20 mm to 40 mm, apply the spacer on the adjustable paper guide (see following figure), then adjust the paper width.



NOTE: For ease of reference, it is represented only the internal printer without external plastic chassis.




5.2 Adjusting the alignment sensors

The device is equipped with two mobile sensors for the detection of the alignment black mark placed both on the thermal side and on the non-thermal side of paper as shown in the following figure.


The device user will need to manually move these mobile sensors according to the position and the type of the black mark on the paper (see next paragraphs).

To use these sensors, you must set the “Notch/B.Mark Position” setup parameter on the correct value (see chapter 6).



NOTE: For ease of reference, for some models is represented only the internal printer group without the external plastic chassis or triple feeder.

To adjust the mobile sensors position according to the black mark position and type on paper, open the device cover and move the sensors to the desired position using a small screwdriver or a pointed object.



NOTES:



For ease of understanding, the image shows the two flats represented in the same plane.

For ease of reference, for some models is represented only the internal printer group without external plastic chassis or triple feeder.




5.3 Switch device on


**KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL**





NOTE: For ease of reference, it is represented only the printer group without triple feeder.

TK302 STD, TK303 STD, TK302 TF**1**

Rotate the captive knob to unlock
the connectors cover.

2


Remove the
connectors cover.

3

Connect the power supply cable to device.
Use the type of electrical power supply
indicated on label.



4




Connect the 220V power supply cable to the power supply unit and to outlet.

6

PRINTER READY
01/01/17 12:00:00

The display turns on with standby message.
The device is ready.

5



Switch the device on by pressing the ON/OFF key on the power supply cable.


NOTE: For ease of reference, it is represented only the printer group without triple feeder.

5.4 Loading the paper roll

To change the paper roll proceed as follows. At every paper change, check inside the device to locate and remove any scraps of paper.


KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, TK302 STD, TK303 STD

1 TK302 STD, TK303 STD




Open the
upper plastic cover.

2



Push the opening lever
in the direction shown in the figure.


3



ATTENTION:
Pay attention to the
exposed cutter blade.

Open the upper cover
of the device.


4



Adjust the paper width and the notch sensors
position (see previous paragraphs).




5




Close the upper cover
of the device.

6



Insert the paper into the input mouth so that it unrolls correctly. Be sure that the paper is correctly positioned into paper guides.


7



Wait until the paper is automatically loaded.

8


TK302 STD, TK303 STD




Close the
upper plastic cover.

NOTE:


For ease of reference, in some figure is represented only the internal printer without external plastic chassis.

KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF**1 TK302 TF**

Open the
upper plastic cover.


2

Push the opening lever
in the direction shown in the figure.

3

ATTENTION:
Pay attention to the
exposed cutter blade.


Open the upper cover
of the device.

4

Adjust the notch sensors position
(see previous paragraphs).




5




Close the upper cover
of the device.

7



Wait until the paper is
automatically loaded.


6



ATTENTION:
In case of ticket with TAG RFID, is recommended to insert the ticket into the central feeder (paper input feeder 2). The use of paper inputs 1 and 3 causes a slight bending of paper and therefore the integrity of the TAG RFID is not guaranteed. Before proceeding, check with a sample ticket.

Insert the paper into one of the input feeders so that it unrolls correctly. Be sure that the paper is correctly positioned into paper guides.

8

TK302 TE

Close the
upper plastic cover.

NOTE:

For ease of reference, in some figures is represented only the internal printer without external plastic chassis.


5.5 Issuing ticket

The device allows you to choose between different operating modes for the issuance of printed tickets. The operating modes shown in following images, depend on the settings of configuration parameters and commands sent to the device.

NOTE: For ease of reference, for some models is represented only the internal printer group without external plastic chassis or triple feeder.


Standard mode

1



The device starts the ticket printing.

2




When printing ends, the device cuts the ticket printed
that is issued from the paper output.




“PRESENT” mode (KPM302 EJ, KPM303 EJ, KPM302 TF-EJ)

1



The device starts the ticket printing.

2




When printing ends, the device cuts the ticket printed
and hold it between the ejector rollers.



3

Ticket withdrew




The user withdraws the ticket printed.




“EJECT” mode (KPM302 EJ, KPM303 EJ, KPM302 TF-EJ)

1



The device starts the ticket printing.


2



When printing ends, the device cuts the ticket printed
and hold it between the ejector rollers.



3



The device ejects the ticket printed.


NOTE:

To enable this issuing method, you need to correctly set the operation mode of the ejector device with the command 0x1D 0x65 0x05 (see the device commands manual).



“PRESENT” mode (KPM302 vSEL, KPM303 vSEL, KPM302 TF-vSEL)


1



The device starts the ticket printing.




2



When printing ends, the device cuts the ticket printed
and hold it between the ejector rollers.

3



The user withdraws the ticket printed.


NOTE:

To enable this issuing method, you need to correctly set the operation mode of the selector device with the command 0x1D 0x70 0x6F (see the device commands manual).



“EJECT” mode (KPM302 vSEL, KPM303 vSEL, KPM302 TF-vSEL)


1



The device starts the ticket printing.




2



When printing ends, the device cuts the ticket printed
and hold it between the ejector rollers.

3




The device ejects the ticket printed.

NOTE: To enable this issuing method, you need to correctly set the operation mode of the selector device with the commands 0x1D 0x70 0x6F and 0x1D 0x65 0x05 (see the device commands manual).



“COLLECT” mode (KPM302 vSEL, KPM303 vSEL, KPM302 TF-vSEL)


1



The device starts the ticket printing.




2



When printing ends, the device cuts the ticket printed and hold it between the ejector rollers.
The tilting slide is lifted and the ticket printed is driven into the ejection canal.

3




The device collects the ticket printed.

NOTE: To enable this issuing method, you need to correctly set the operation mode of the selector device with the commands 0x1D 0x70 0x6F and 0x1D 0x65 0x05 (see the device commands manual).




"PRESENT" mode (KPM302 TF-hSEL)

1



The device starts the ticket printing.

2




When printing ends, the device cuts the ticket printed
and hold it between the ejector rollers.



3

Ticket withdrew




The user withdraws the ticket printed.

NOTE: To enable this issuing method, you need to correctly set the operation mode of the selector device with the command 0x1D 0x70 0x6F (see the device commands manual).




“EJECT” mode (KPM302 TF-hSEL)

1




The device starts the ticket printing.

2



When printing ends, the device cuts the ticket printed
and hold it between the ejector rollers.

3




The device ejects the ticket printed.

NOTE: To enable this issuing method, you need to correctly set the operation mode of the selector device with the commands 0x1D 0x70 0x6F and 0x1D 0x65 0x05 (see the device commands manual).




“COLLECT” mode (KPM302 TF-hSEL)

1



The device starts the ticket printing.


2



When printing ends, the device cuts the ticket printed and hold it between the ejector rollers.
The tilting slide is lifted and the ticket printed is driven into the ejection canal.



3



The device collects the ticket printed.

NOTE: To enable this issuing method, you need to correctly set the operation mode of the selector device with the commands 0x1D 0x70 0x6F and 0x1D 0x65 0x05 (see the device commands manual).




6 CONFIGURATION

6.1 Configuration mode


To enter the configuration mode and print a setup report with the operating parameters of the device, proceed as follows.

**KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL**






3



**Enter
printer
setup**




**Enter
ethernet
setup**

Press the LF LINE FEED key to enter the configuration mode
or press the FF FORM FEED key to print the setup report with the Ethernet parameters.

TK302 STD, TK303 STD, TK302 TF


1



While pressing the LF LINE FEED key, switch on the device
by pressing the ON/OFF key on the power supply cable.




2




The device prints the report with
the settings parameters.

3



**Enter
printer
setup**



**Enter
ethernet
setup**

Press the LF LINE FEED key to enter the configuration mode
or press the FF FORM FEED key to print the setup report with the Ethernet parameters.



6.2 Setup report

The following figures show the device setup reports. The shown values for parameters are sample values; for the list and the description of device parameters see following paragraphs.

PRINTER NAME and FIRMWARE MODULES RELEASE	<pre><device name> SCODE: <code> - rel 1.00 BCODE: <code> - rel 1.00 FCODE: <code> - rel 1.00 UCODE: <code> - rel 1.00 DCODE: <code> - rel 1.00 CPLD - rel 1.00</pre>
PRINTER STATUS	<p>PRINTER SETTINGS</p> <pre>PRINTER TYPE <device model> Barcode Reader Not Present RFID module Not Present PRINTING HEAD TYPE <head model> INTERFACE RS232 ETHERNET TYPE 10/100Base-TX PROGRAM MEMORY TEST.....OK DYNAMIC RAM TEST.....OK EEPROM TEST.....OK CUTTER TEST.....OK PRINTER HEAD Rav 561 HEAD VOLTAGE [V] = 24.55 HEAD TEMPERATURE [°C] = 26 POWER ON COUNTER = 3 PAPER PRINTED [cm] = 10 CUT COUNTER = 35</pre>
PRINTER PARAMETERS	<pre>Printer Emulation.....: CUSTOM/POS RS232 Baud Rate: 115200 bps RS232 Data Length....: 8 bits/chr RS232 Parity: None RS232 Handshaking: Xon/Xoff Busy Condition: RxFull USB Mass Storage.....: Enabled USB Address Number ...: 0 Print Mode: Normal Autofeed: CR disabled Chars / inch: A=15 B=20 cpi Speed / Quality: Normal Paper Width.....: 82 mm Paper Threshold....: 60% Notch/B.Mark Position.....: Bottom Notch/B.Mark Threshold.....: 40% Notch Distance [mm]: +00.0 Notch/B.Mark Min. Width.....: 0 mm Ticket Locking.....: Disabled PaperEnd Buffer Clear ..: Disabled Ticket Management....: Disabled Paper End Management ..: Print All RFID Module Baud Rate ..: 38400 bps Print Density: 0%</pre>
KEYS FUNCTIONS	<pre>[LF] enter Printer Setup [FF] enter Ethernet Setup [S1] enter Clock Setup [S2] skip Setup</pre>



KEYS FUNCTIONS

[LF] enter Printer Setup
[FF] enter Ethernet Setup
[S1] enter Clock Setup
[S2] skip Setup

*ETHERNET
PARAMETERS*

DHCP Client : **Disabled**
FTP Server : **Disabled**

IP Address : **192.168. 0. 1**
Subnet Mask : **255.255.240. 0**
Default Gateway..... : **192.168. 0. 5**

MAC Address : **00-0E-E2-02-0B-0D**

For advanced printer setup please connect to the site
http://192.168.0.1



6.3 Printer status

The device operating status is indicated in the configuration print-out in which, next to the name of the components displayed, the following information is given:

PRINTER TYPE	<i>device model</i>
Barcode Reader	<i>presence of the barcode reader</i>
RFID module	<i>presence of the RFID reader/writer</i>
PRINTING HEAD TYPE	<i>print head model</i>
INTERFACE	<i>interface present</i>
ETHERNET TYPE	<i>Ethernet connection type</i>
PROGRAM MEMORY TEST	<i>OK appears if functioning and NOT OK if faulty</i>
DYNAMIC RAM TEST	<i>OK appears if functioning and NOT OK if faulty</i>
EEPROM TEST	<i>OK appears if functioning and NOT OK if faulty</i>
CUTTER TEST	<i>OK appears if functioning and NOT OK if faulty</i>
PRINTER HEAD Rav	<i>resistance of a dot head</i>
HEAD VOLTAGE	<i>voltage of the head</i>
HEAD TEMPERATURE	<i>temperature of the head</i>
POWER ON COUNTER	<i>number of power-ups made</i>
PAPER PRINTED	<i>centimetres of paper printed</i>
CUT COUNTER	<i>number of cuts made</i>



6.4 Printer parameters

The device allows the configuration of the parameters listed in the following table.

The parameters marked with the symbol ^D are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile memory.

PRINTER EMULATION

Available emulations for the device:

CUSTOM/POS
SVELTA ^D

RS232 BAUD RATE

Communication speed of the serial interface:

1200	2400
4800	9600
19200	38400
57600	115200 ^D

NOTE: Parameter valid only with serial interface.

RS232 DATA LENGTH

Number of bit used for characters encoding:

8 bits/car ^D
7 bits/car

NOTE: Parameter valid only with serial interface.

RS232 PARITY

Bit for the parity control of the serial interface:

None ^D = parity bit omitted
Even = even value for parity bit
Odd = odd value for parity bit

NOTE: Parameter valid only with serial interface.

RS232 HANDSHAKING

Handshaking:

XON/XOFF ^D = software handshaking
Hardware = hardware handshaking (CTS/RTS)

NOTE: Parameter valid only with serial interface.

BUSY CONDITION

Activation mode for the Busy signal:

RXFull ^D = Busy signal is activated when the buffer is full
OffLine/ RXFull = Busy signal is activated when the device is both in OffLine status and the buffer is full

NOTE: Parameter valid only with serial interface.

**USB MASS STORAGE**

Sharing mode from Mass Storage:

Disabled = sharing mode disabled

Enabled^D = sharing mode enabled

USB ADDRESS NUMBER

Numerical address code for the univocal identification of the USB device (in case of more than a USB device connected with the same PC):

0 ^D	2	4	6	8
1	3	5	7	9

PRINT MODE

Printing mode:

Normal^D = enables printing in normal writing way

Reverse = enables printing rotated 180 degrees

AUTOFED

Setting of the Carriage Return character:

CR disabled^D =Carriage Return disabled

CR enabled = Carriage Return enabled

NOTE: The parameter is printed only with CUSTOM/POS emulation enabled.

CHARS / INCH

Font selection:

KPM302 STD, KPM302 EJ, KPM302 vSEL, KPM302 TF, KPM302 TF-EJ,
KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 STD, TK302 TF

A = 11 cpi, B = 15 cpi

A = 15 cpi, B = 20 cpi^D

KPM303 STD, KPM303 EJ, KPM303 vSEL, TK303 STD

A = 16 cpi, B = 23 cpi

A = 23 cpi, B = 30 cpi^D

NOTES:

CPI = Characters Per Inch

The parameter is printed only with CUSTOM/POS emulation enabled.

SPEED / QUALITY

Setting of printing speed and printing quality:

High Quality

Normal

High Speed^D



PRINT WIDTH

Width of printing area:

20 mm	34 mm	48 mm	62 mm	76 mm
22 mm	36 mm	50 mm	64 mm	78 mm
24 mm	38 mm	52 mm	66 mm	80 mm
26 mm	40 mm	54 mm	68 mm	82 mm ^D
28 mm	42 mm	56 mm	70 mm	
30 mm	44 mm	58 mm	72 mm	
32 mm	46 mm	60 mm	74 mm	

PAPER THRESHOLD

Threshold value (in percent) for the recognition of paper presence by the paper presence sensor:

30%	40% ^D	50%
60%	70%	80%
90%		

NOTCH/B.MARK POSITION

Position of the alignment notch and choice of appropriate notch sensor:

- Disabled ^D* = the notch alignment is not performed
Bottom = the notch position is detected by the lower sensor (reflection)
Top = the notch position is detected by the upper sensor (reflection)
Transparence = the notch position is detected by both the sensors (transparence)

NOTCH/B.MARK THRESHOLD

Threshold value (in percent) for the recognition of notch presence by notch sensor:

30%	40%	50%
60% ^D	70%	80%
90%		

NOTE: If the "Notch/B.Mark Position" parameter is disabled, this parameter is not printed.

NOTCH DISTANCE

"Notch Distance" is the minimum distance (in mm) between the upper edge of ticket and the notch (see chapter 11).

The numeric value of distance is made up with the following four parameters for the setting of three digits (two for the integer part of number and one for the decimal part) and of sign:

NOTCH DISTANCE SIGN

Sign setting:

- + ^D* = positive distance
- = negative distance

NOTCH DISTANCE [mm x 10]

Setting the digit for tens:

0 ^D	2	4	6	8
1	3	5	7	9

NOTCH DISTANCE [mm x 1]

Setting the digit for units:

0 ^D	2	4	6	8
1	3	5	7	9



NOTCH DISTANCE [mm x .1] Setting the digit for decimals:

0	D	2	4	6	8
1		3	5	7	9

NOTES:

For example, to set a positive notch distance value of 15mm, modify the parameters as follows:

Notch Distance Sign	= +
Notch Distance [mm x 10]	= 1
Notch Distance [mm x 1]	= 5
Notch Distance [mm x .1]	= 0

If the "Notch/B.Mark Position" parameter is disabled, parameters for the "Notch Distance" are not printed.

NOTCH/B.MARK MIN. WIDTH

Minimum length for the alignment notch:

0 mm	D	5 mm	10 mm	15 mm	20mm
1 mm		6 mm	11 mm	16 mm	
2 mm		7 mm	12 mm	17 mm	
3 mm		8 mm	13 mm	18 mm	
4 mm		9 mm	14 mm	19 mm	

NOTES: If the "Notch/B.Mark Position" parameter is disabled, this parameter is not printed.

This parameter describes the dimensions of the alignment notch in order to avoid that other graphics on ticket is detected erroneously as notch.

TICKET LOCKING

This parameter enables/disables the block of paper inside the device when the ticket is not cut by the cutter, but is presented for manual tear off by the user:

KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, TK302 STD, TK303 STD

*Disabled D = paper block disabled
Enabled = paper block enabled*

KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF

*Disabled D = paper block disabled
By Printer = the motor remain switched on also at the printing end
By Feeder = stops the paper of the not active (idle) feeders in order to avoid that the paper parked in a idle feeder, is dragged inside the printer
Complete = ticket locking by printer and feeder (combination of the two previous effects)*

NOTE: If the "Notch/B.Mark Position" parameter is disabled, the parameter is not printed.

PAPEREND BUFFER CLEAR

Cleaning mode of data in receive buffer, if the printing is stopped due to lack of paper:

*Disabled D = Data remain in the receive buffer. When the paper runs out, the device keeps the remaining data in receive buffer and prints the remaining portion of ticket after that the new paper is loaded.
Enabled = When the paper runs out, all data in the receive buffer are deleted.*



TICKET MANAGEMENT

This parameter allows the ticket management:

Disabled^D = no check

Short Ticket = it is possible to manage tickets with length less than the distance between notch sensor and printing line

Check First = before printing, the device checks the integrity of the first ticket

Stub+Ticket = it is possible to manage tickets with stub

PAPER END MANAGEMENT

KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF

Management of the paper end sensors of triple feeder:

Print All^D = when the paper end sensor of a feed line of the triple feeder detects the paper end, it is not possible to change the feed line until all tickets remaining in that feed line are printed (so that the paper sensors of the printer will have detected the end of paper)

Eject = when the paper end sensor of a feed line of the triple feeder detects the paper end, the device automatically ejects the paper remaining on that feed line and prints diagonal voiding lines on the remaining tickets

Retract = when the paper end sensor of a feed line of the triple feeder detects the paper end, the device performs a paper retracting up to the parking position

RFID MODULE BAUD RATE

Communication speed of RFID module:

115200	38400 ^D	9600	2400
57600	19200	4800	1200

NOTE: if the RFID module is not recognized in the printer status ("RFID module = Not Present"), set this parameter on the correct value.

PRINT DENSITY

Adjusting the printing density:

-50%	-12%	+25%
-37%	0 ^D	+37%
-25%	+12%	+50%



6.5 Ethernet parameters

The device allows the configuration of the parameters listed in following table.

The parameters marked with symbol ^D are the default values.

Settings remain active even after the device has been turned off and they are stored in non-volatile memory.

DHCP CLIENT	<i>Setting of DHCP protocol:</i> <i>Disabled ^D = protocol disabled</i> <i>Enabled = protocol enabled</i>
FTP SERVER	<i>Setting of FTP server:</i> <i>Disabled ^D = server disabled</i> <i>Enabled = server enabled</i>
IP ADDRESS	<i>IP address of device; this parameter is assigned by network administrator.</i> NOTE: Press FORM FEED key to modify the value of highlighted digit. Pressing LINE FEED key to move cursor on next digit (if cursor is on the latest digit, proceed to next parameter by pressing LINE FEED key).
SUBNET MASK	<i>This parameter identifies local network address.</i> NOTE: Press FORM FEED key to modify the value of highlighted digit. Pressing LINE FEED key to move cursor on next digit (if cursor is on the latest digit, proceed to next parameter by pressing LINE FEED key).
DEFAULT GATEWAY	<i>This parameter identifies Gateway IP address used to send applications to external network.</i> NOTE: Press FORM FEED key to modify the value of highlighted digit. Pressing LINE FEED key to move cursor on next digit (if cursor is on the latest digit, proceed to next parameter by pressing LINE FEED key).
DOMAIN NAME SYSTEM	<i>This parameter identifies Domain Name System (DNS).</i> NOTE: This parameter is not printed on the setup report, because it is not modifiable during the setup procedure. To set this parameter, enter the Setup.ini file (see par.13.9).
TCP PRINTER PORT	<i>This parameter sets TCP port number.</i> NOTE: This parameter is not printed on the setup report, because it is not modifiable during the setup procedure. To set this parameter, enter the Setup.ini file (see par.13.9).
MAC ADDRESS	<i>This is the number, provided by the constructor, that identifies the device; this number is univocal.</i> NOTE: This parameter can't be modified by set up.

ATTENTION: Any changes to network parameters will interrupt browser connection. If the server not responding you must reconnect to the new IP address set.



6.6 Hexadecimal dump

This function is used for the diagnosis of the characters received from the communications port. Characters are printed as hexadecimal code and the corresponding ASCII code (see below). Each line is preceded by a counter in hexadecimal that indicates the number of bytes received.

During the startup, if you hold down the FEED key, the device enters the self-test routine and print the setup report. The device remains in standby until a key is pressed or characters are received through the communication port (Hexadecimal Dump mode). For each character sent, the ticket shows the hexadecimal value and the ASCII codes (if the characters are underlined, the receive buffer is full). Shown below is an example of a Hexadecimal Dump:

HEXADECIMAL DUMP

31	32	33	34	35	...	12345	...
39	30	31	32	33	...	90123	...
37	38	39	75	69	...	789ui	...
68	6B	6A	73	64	...	hkjsd	...
73	64	66	6B	6A	...	sdfkj	...
66	73	64	66	6B	...	fsdfk	...
65	69	6F	79	75	...	eioyu	...
6F	72	69	75	77	...	oriuw	...
6F	75	77	65	72	...	ouwer	...
77	65	72	69	6F	...	werio	...
72	69	6F	75	77	...	riouw	...
6B	6C	73	64	66	...	klsdf	...
64	66	6B	73	64	...	dfksd	...
73	64	66	6B	6A	...	sdfkj	...
66	6B	F2	6A	73	...	fk≥j	...
6A	6B	6C	68			jklh	



6.7 Calendar clock

The device is equipped with a Real Time Clock. During power-up, held down the LF LINE FEED key to enter in the device configuration mode. Press the S1 key to enter in the clock configuration (see following figure).

Press the LF LINE FEED key to modify date/time; the device will print the updated date and time.

Follow the instructions printed on the paper for the key functionality. The highlighted digit (the number is written in negative mode) indicates the digit to be modified. Press the LF LINE FEED key to modify the value of the highlighted digit; every single LF LINE FEED key pressure increases of 1 his value. Once the value 9 is reached the counting starts again from 0.

Press the FF FORM FEED key to move the cursor on the next digit; if the cursor position is on the latest digit you can proceed to next parameter by pressing the FF FORM FEED key again.

Press the S2 key to exit and terminate the setting procedure.

CLOCK SETUP

[LF] to modify date/time

[FF] to next field

[S2] to exit

01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00
01/01/17 12:00:00

Date Time Setting :
01/01/17 12:00:00

NOTE:

For models without Real Time Clock, data and time setting remains until the device shutdown.




TK302 STD, TK303 STD, TK302 TF

The device is equipped with a Real Time Clock. Proceed as follows to set the clock.

1


LF = ENTER SETUP...
FF = EXIT SETUP...



During power-up, press the LF LINE FEED key to enter the setup configuration.

2


Set-Up type...
Printer Set/Up



Press the LF LINE FEED key to select the Real Time Clock settings.

3

Set-Up type...
Real Time Clock



Press the FF FORM FEED key to confirm the selection.


The date/time values will be displayed.

Follow the instructions printed on the paper.

4

0>1>2>3>4>5>6>7>8>9

Clock Setup
01/01/17 12:00:00




The digit to be modified is highlighted.
Press the LF LINE FEED key to modify the value;
every press on the button increases the value by one.
Once the max selectable value is reached the
counting starts again from 0.

5

0>1>2>3>4>5>6>7>8>9

Clock Setup
01/01/17 12:00:00



Use the FF FORM FEED key to move the cursor
on the next digit; if the cursor position is
on the latest digit, press the FF FORM FEED key
to exit and save the date/time entered.
Then the device is ready.






7 MAINTENANCE

7.1 Printer paper jam


1



Open the upper covers of the device
(see previous paragraphs).


2

TK302 STD, TK303 STD




Open the plastic
front cover.

3



Open the front cover
of the device.


4



Remove the damaged paper and check the presence
for paper scraps inside the device. Carefully remove all
paper scraps. If necessary use tweezers.




5



Close the front cover
of the device.


7



Close the upper covers of the device
(see previous paragraphs).


6

TK302 STD, TK303 STD



Close the plastic
front cover.

8



Insert the paper
(see previous paragraphs).

NOTE: For ease of reference, in some figure is represented only the internal printer without external plastic chassis or triple feeder.




7.2 Triple feeder paper jam

KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF

In case of paper jam inside the triple feeder, the green led that corresponds to the input paper jammed flashes quickly. In this case, contact the customer service.

1



The green LED for
the feeder jammed flashes quickly.

2



Customer Service Department

Send an e-mail to the customer service
(see chapter 12).

NOTE:

For ease of reference, in some figure is represented only the internal printer without external plastic chassis.



7.3 Planning of cleaning operations

The regular cleaning of the device keeps the print quality and extends its life. The following table shows the recommended planning for the cleaning operations.

EVERY PAPER CHANGE

Printing head	Use isopropyl alcohol
Platen roller	Use isopropyl alcohol
Window for barcode reading ⁽¹⁾	Use a soft cloth

EVERY 5 PAPER CHANGES

Cutter	Use compressed air
Paper path	Use compressed air or tweezers
Sensors	Use compressed air
Triple feeder	Use the dedicated cleaning kit ⁽²⁾

EVERY 6 MONTHS OR AS NEEDED

Case	Use compressed air or a soft cloth
Display	Use a soft cloth ⁽³⁾

For specific procedures, see the following pages.

NOTES:

If you use the device in dusty environments, you must reduce intervals between cleaning operations.

For ease of reference, in the following pages, for some models is represented only the printer group without external plastic chassis or triple feeder.

(1) Only for models with barcode reader.

(2) For the cleaning kit for triple feeder, contact the customer service (for KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF).

(3) Don't use any ammonia-based product (for TK302 STD, TK303 STD, TK302 TF)




7.4 Cleaning

For periodic cleaning of the device, see instructions below.


Sensors

1



Disconnect the power supply cable and open all the device covers (see previous paragraphs).

2



ATTENTION:


Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.
To remove paper scraps, use tweezers or compressed air.



Clean all the device sensors by using compressed air.


Paper path

1



Disconnect the power supply cable and open the upper device covers (see previous paragraphs).

2



ATTENTION:

Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.
To remove paper scraps, use tweezers or compressed air.




Clean the area involved in the passage of paper by using compressed air.




Printing head

1



Disconnect the power supply cable and open the upper device covers (see previous paragraphs).

2



ATTENTION:


Do not use solvents, or hard brushes.
Do not let water or other liquids get inside the machine.
To remove paper scraps, use tweezers or compressed air.



Clean the printing head by using a non-abrasive cloth moistened with isopropyl.


Platen roller

1



Disconnect the power supply cable and open the upper device covers (see previous paragraphs).

2




ATTENTION:


Do not use solvents, or hard brushes.
Do not let water or other liquids get inside the machine.
To remove paper scraps, use tweezers or compressed air.



Clean the platen roller by using a non-abrasive cloth moistened with isopropyl.

Cutter**1**


Disconnect the power supply cable and open all the device covers (see previous paragraphs).

2**ATTENTION:**


Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.
To remove paper scraps, use tweezers or compressed air.



Clean the cutter
by using compressed air.

Case**1**

Disconnect the power supply cable.

2**ATTENTION:**

Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.




To clean the device,
use compressed air or a soft cloth.



Triple feeder

1



Disconnect the power supply cable and open the upper device covers (see previous paragraphs).


2



Customer Service Department


Contact the customer service
for the cleaning kit for the triple feeder.

3



Insert the edge with the rounded corners of the ticket of the cleaning kit in each of the three feeders until it comes out from the triple feeder a few of centimeters.

4




ATTENTION:


Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.
To remove paper scraps, use tweezers or compressed air.



Pull out the ticket of the cleaning kit
by sliding it into the triple feeder.

Windows for barcode reading**1**


Disconnect the power supply cable and open the upper device covers (see previous paragraphs).

2**ATTENTION:**


Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.



Clean the window for barcode reading
by using a soft cloth.

Display**1**

Disconnect the power supply cable.

2**ATTENTION:**

Do not use alcohol, solvents, or hard brushes.
Do not let water or other liquids get inside the machine.
Do not use ammonia-based products .



To clean the display,
use compressed air or a soft cloth.



7.5 Upgrade firmware

WARNING: During communication between PC and device for the firmware update it is strictly forbidden to disconnect the communication cable or to remove the power supply of the devices not to endanger the proper functioning of the machine.

NOTES:

The latest firmware of the device is available in the download area of the web site www.custom.biz

Install on the PC used for device upgrading the UPGCEPRN software available in the download area of the web site www.custom.biz.


Update via serial interface

Proceed as follows:


1. Write down the product code (14 digits) printed on the product label (see paragraph 3.5).
2. Go to the web site www.custom.biz and download the appropriate firmware release from the DOWNLOAD area.
3. Print the setup report (see chapter 6).
4. Switch off the device.
5. Connect the device to the PC using a serial cable (see paragraph 4.5).
6. Switch on the device.
7. Launch the software UPGCEPRN.
8. Select the update file .PSW location:

Firmware rel.:	None	Printer type:	None
Hardware rel.:	None	Select port:	None
PSW Version :	None		
File (*.cfg) :	None		
File (*.psw):	<input type="file"/> <input type="button" value="Select (*.psw):"/> <input type="button" value="Begin upgrade"/>		
Data flush status... <input type="text"/>			
Upgrade status:		Port config:	
No upgrade thread active...		Communication port not init	

9. Select the serial communication port (e.g. COM1):



10. Detecting and setting of the parameters necessary for serial communication are performed automatically and then updating begins.
11. After a few minutes a message on the screen warns that the update is completed.



12. Print a new setup report to verify the new firmware release.



Update via USB interface

ATTENTION:


Only during the firmware update, the connection between PC and device must be direct, without the use of HUB device.

Only during the firmware update, do not connect or disconnect other USB devices.


NOTE: For communication via USB you must install on PC the device driver available in the download area of the web site www.custom.biz.

Proceed as follows:


1. Write down the product code (14 digits) printed on the product label (see paragraph 3.5).
2. Go to the web site www.custom.biz and download the appropriate firmware release from the DOWNLOAD area.
3. Print the setup report (see chapter 6).
4. Switch off the device.
5. Connect the device to the PC using a USB cable (see paragraph 4.5).
6. Switch on the device.
7. Launch the software UPGCEPRN.
8. Select the update file .PSW location:

Firmware rel.:	None	Printer type:	None
Hardware rel.:	None	Select port:	None
PSW Version :	None		
File (*.cfg) :	None		
File (*.psw):	<input type="file"/> <input type="button" value="Select (*.psw):"/>  <input type="button" value="Begin upgrade"/>		
Data flush status...  <input style="width: 240px; height: 15px; margin-top: 10px;" type="text"/>			
Upgrade status:		Port config:	
No upgrade thread active...		Communication port not init	

9. Select item USB and then select the USB device among those proposed (e.g. device1):



10. After a few minutes a message on the screen warns that the update is completed.



11. Print a new setup report to verify the new firmware release.





8 SPECIFICATION

8.1 Hardware specification

GENERAL

Sensors	Head temperature, paper presence, paper presence on output, mobile detectors of black mark or translucent gap/hole (setting by software), front and upper cover open, external low paper, tilting slide position (only for models with selector)
MTBF ⁽¹⁾	84 080 hours
Noise	
KPM302 STD, KPM302 EJ, KPM302 vSEL	74 dB
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL	75 dB
KPM303 STD, KPM303 EJ, KPM303 vSEL	73 dB
TK302 STD, TK303 STD, TK302 TF	76.7 dB
Emulations	CUSTOM/POS, SVELTA
INTERFACES	
USB port	12 Mbit/s
RS232 serial port	from 1200 bps to 115200 bps
ETHERNET port	10 Mbit/s, 100 Mbit/s
MEMORIES	
Receive buffer	64 Kbytes
Flash memory	16 Mbytes
Graphic memory	Logos dynamic management (max 2MB graphic memory)
Memory card SD/MMC	Capacity = max 2 Gbytes



PRINTER

Resolution

KPM302 STD,
KPM302 EJ, KPM302 vSEL,
KPM302 TF,
KPM302 TF-EJ, KPM302 TF-vSEL,
KPM302 TF-hSEL,
TK302 STD, TK302 TF 203 dpi (8 dot/mm)

KPM303 STD,
KPM303 EJ,
KPM303 vSEL,
TK303 STD 304 dpi (12 dot/mm)

Printing method Thermal, fixed head

Head life ⁽²⁾

Abrasion resistance ⁽³⁾ 100 Km (with recommended paper)

Pulse durability 100 M (12.5% duty cycle)

Printing mode Normal, 90°, 180°, 270°

Printing format Height/Width from 1 to 8, bold,
reverse, underlined, italic

Character font

CUSTOM/POS emulation PC437, PC850, PC860, PC863, PC865, PC858 (euro),
2 TrueType fonts ⁽⁴⁾

CUSTOM/POS emulation
(models with simplified Chinese font) PC437, PC850, PC860, PC863, PC865, PC858 (euro), GB2312,
2 TrueType fonts ⁽⁴⁾

CUSTOM/POS emulation
(models with traditional Chinese font) PC437, PC850, PC860, PC863, PC865, PC858 (euro), BIG5,
2 TrueType fonts ⁽⁴⁾

SVELTA emulation 20 embedded fonts and 2 TrueType fonts ⁽⁴⁾

Printable barcode UPCA, UPCE, EAN13, EAN8, CODE39, ITF,
CODABAR, CODE93, CODE128, CODE32,
PDF417, DATAMATRIX, AZTEC, QRCODE



Printing speed ⁽²⁾⁽⁵⁾

KPM302 STD, KPM302 EJ, KPM302 vSEL,
KPM302 TF, KPM302 TF-EJ,
KPM302 TF-vSEL, KPM302 TF-hSEL,
TK302 STD, TK302 TF

High quality = 110 mm/s
Normal = 170 mm/s
High speed = 200 mm/s

KPM303 STD, KPM303 EJ, KPM303 vSEL,
TK303 STD

High quality = 100 mm/s
Normal = 125 mm/s
High speed = 150 mm/s

PAPER

Type of paper

Thermal rolls, heat-sensitive side on outside of roll
Thermal fan-fold module with alignment notch

Paper width

KPM302 STD, KPM303 STD, TK302 STD,
TK303 STD

from 20 mm to 82.5 mm (2 mm step)

KPM302 EJ, KPM303 EJ, KPM302 vSEL,
KPM303 vSEL

from 40 mm to 82.5 mm (2 mm step)

KPM302 TF, KPM302 TF-EJ,
KPM302 TF-vSEL, KPM302 TF-hSEL,
TK302 TF

54 mm, 60 mm, 82.5 mm

models with CUT&HOLD kit (optional)

from 40 mm to 82.5 mm (2 mm step)

Paper weight

KPM302 STD, KPM303 STD, KPM302 EJ,
KPM303 EJ, KPM302 vSEL, KPM303 vSEL,
TK302 STD, TK303 STD

from 80 g/m² to 255 g/m²

KPM302 STD, KPM303 STD, KPM302 EJ,
KPM303 EJ, KPM302 vSEL, KPM303 vSEL,
TK302 STD, TK303 STD
in BURSTER configuration

from 100 g/m² to 250 g/m²

KPM302 TF, KPM302 TF-EJ,
KPM302 TF-vSEL, KPM302 TF-hSEL,
TK302 TF

from 100 g/m² to 255 g/m²

KPM302 TF, KPM302 TF-EJ,
KPM302 TF-vSEL, KPM302 TF-hSEL,
TK302 TF
in BURSTER configuration

from 100 g/m² to 250 g/m²



Paper thickness (KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF)	max 280 µm
Minimum ticket length (KPM302 vSEL, KPM303 vSEL, KPM302 TF-vSEL, KPM302 TF-hSEL)	50 mm
External roll diameter ⁽⁶⁾	max. 300 mm
Internal roll core diameter	25 mm (+ 1mm)
Core thickness	2 mm (+ 1mm)
Paper end	Not attached to roll core
Core type	Cardboard or plastic
CUTTER	
Paper cut	Total cut
Estimated life ⁽²⁾	1 500 000 cuts
DEVICES ELECTRICAL SPECIFICATIONS	
Power supply	24 Vdc ±10%
Medium consumption ⁽⁷⁾	4.10 A
Typical consumption ⁽⁵⁾	
KPM302 STD, KPM302 EJ, KPM302 vSEL, TK302 STD	0.8 A
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF	1 A
KPM303 STD, KPM303 EJ, KPM303 vSEL, TK303 STD	0.6 A
Standby consumption	0.14 A



POWER SUPPLY ELECTRICAL SPECIFICATIONS cod.963GE020000043

Power supply voltage	Auto Range, 90-132 VAC & 190-264 VAC
Frequency	from 47 Hz to 63 Hz
Current (output)	24 V, 4.17 A
Power	100 W

ENVIRONMENTAL CONDITIONS

Operating temperature	
models with Real Time Clock	from 0 °C to 50 °C
models without Real Time Clock	from -20 °C to 70 °C
Relative humidity	
KPM302 STD, KPM302 EJ, KPM302 vSEL, KPM303 STD, KPM303 EJ, KPM303 vSEL, KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL	from 10% Rh to 80% Rh
TK302 STD, TK303 STD, TK302 TF	from 10% Rh to 85% Rh
Storage temperature	from -20 °C to +70 °C
Storage relative humidity	from 10% Rh to 90% Rh

NOTES:

- (1) : Control board.
- (2) : Respecting the regular schedule of cleaning for the device components.
- (3) : Damages caused by scratches, ESD and electromigration are excluded.
- (4) : "Veramono.ttf" and "Vera.ttf" are installed on device flash disk. It is possible to install additional TrueType fonts (see par.13.8).
- (5) : Referred to a standard CUSTOM receipt (L=10 cm, Density = 12,5% dots on).
- (6) : For external rolls diameter higher to Ø100 mm it's recommended to use a paper pretensioning device.
- (7) : Referred to the UL measurements (Speed/Quality = Normal, ticket length = 203 mm, 50% dots on, loop = 10 s).



8.2 Character specifications

KPM302 STD, KPM302 EJ, KPM302 vSEL, KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 STD, TK302 TF

Character set	3		
Character density	11 cpi	15 cpi	20 cpi
Number of columns	35	45	64
Chars / second	2900	3800	5300
Lines / second	83	83	83
Characters (L x H mm)-Normal	2.25 x 3	1.75 x 3	1.25 x 3

KPM303 STD, KPM303 EJ, KPM303 vSEL, TK303 STD

Character set	3		
Character density	16 cpi	23 cpi	30 cpi
Number of columns	53	68	96
Chars / second	5300	6800	9600
Lines / second	100	100	100
Characters (L x H mm)-Normal	1.5 x 2	1.2 x 2	0.8 x 2



8.3 Specifications for RFID reader/writer

TRANSPOUNDER SPECIFICATIONS for models with HF RFID reader/writer (ELATEC)

ISO 14443-A:

Mifare Ultralight, Mifare Classic 1K, Mifare Classic 4K,
Mifare Ultralight EV1, Mifare Ultralight C, Mifare Ultralight DESFire,
NTAG 213 (NFC), NTAG 203 (NFC)

Supported transponders

(HF high frequency RFID - 13.5 Mhz)

ISO 14443-B:
SRI-SRx-SRt

ISO 15693:
iCode

TRANSPOUNDER SPECIFICATIONS for models with HF RFID reader/writer (CAEN)

Supported transponders

(UHF ultra high frequency RFID - 900 Mhz)

UHF Gen2



8.4 Specifications for barcode reader

BARCODE READER mod.CX003⁽¹⁾

Scan rate	200 scans/s
Sensor	Liner CCD image sensor
Light source	Red LED lamp, 630 nm
Ambient light (Fluorescent lamp)	3000 LUX max
Resolution	4 mil
Readable barcode	EAN-8, EAN-13, UPC-A, UPC-E, EAN/UPC Add-on, Code 39, Code 32, UCC/EAN/Code 128, Industrial 25, Interleave 25, Matrix 25, Codabar/Nw7, MSI/Plessey RSS (GS1 Databar)

NOTE:

(1) : Only for models with barcode reader.



8.5 Device dimensions

KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL,
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL

Length

KPM302 STD, KPM303 STD	191 mm
KPM302 EJ, KPM303 EJ	212.7 mm
KPM302 vSEL, KPM303 vSEL	272.2 mm
KPM302 TF	307.5 mm
KPM302 TF-EJ	327 mm
KPM302 TF-vSEL, KPM302 TF-hSEL	385.2 mm

Height

KPM302 STD, KPM303 STD KPM302 EJ, KPM303 EJ KPM302 vSEL, KPM303 vSEL	160 mm
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL	168 mm

Width


KPM302 STD, KPM303 STD KPM302 EJ, KPM303 EJ KPM302 vSEL, KPM303 vSEL	3500 g
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL	5200 g

NOTE:

All the dimensions shown in following figure are in millimetres and referred to devices with covers closed.







KPM302 STD, KPM303 STD






KPM302 STD, KPM303 STD (CUT&DROP configuration)






KPM302 STD, KPM303 STD (BURSTER configuration)









KPM302 EJ, KPM303 EJ






KPM302 vSEL, KPM303 vSEL



KPM302 TF




KPM302 TF (CUT&DROP configuration)








KPM302 TF (BURSTER configuration)








KPM302 TF-EJ








KPM302 TF-vSEL





KPM302 TF-hSEL





TK302 STD, TK303 STD, TK302 TF

Length

TK302 STD, TK303 STD	252.1 mm
----------------------	----------

TK302 TF	331 mm
----------	--------

Height

192.6 mm

Width

216 mm

Weight


TK302 STD, TK303 STD	4000 g
----------------------	--------

TK302 TF	4950 g
----------	--------

NOTE: All the dimensions shown in following figure are in millimetres and referred to devices with covers closed and without paper roll.






TK302 STD. TK303 STD





TK302 TF






8.6 Device dimensions with CUT&HOLD kit cod.976AV010000002 (optional)

KPM302 STD, KPM303 STD

Length	214.1 mm
Height	123 mm
Width	160 mm





NOTE: All the dimensions shown in figure are in millimetres and referred to devices with covers closed.



8.7 Device dimensions with paper roll holder cod.974BA010000001 (optional)

TK302 STD, TK303 STD

Length	463.1 mm
Height	195.4 mm
Width	216 mm





NOTE: All the dimensions shown in figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.



8.8 Device dimensions with height reduction kit cod.974BB010000014 (optional)

models with paper roll holder (cod.974BA01000001 - optional)

Length	463.1 mm
Height	185.9 mm
Width	216 mm




NOTE: All the dimensions shown in figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.



8.9 Device dimensions with power supply container cod.974BB010000001 (optional)

models with paper roll holder (cod.974BA010000001 - optional)

Length	463.1 mm
Height	195.4 mm
Width	216 mm




NOTE: All the dimensions shown in figure are in millimetres and referred to devices with covers closed and with Ø178 mm paper roll.



8.10 Device dimensions with metallic ticket tray cod.976BB010000003 (optional)

TK302 STD, TK303 STD, TK302 TF

Length	464 mm
Height	189 mm
Width	216 mm





NOTE: All the dimensions shown in figure are in millimetres and referred to devices with covers closed and without paper roll.



8.11 Device dimensions with plastic ticket tray cod.976BD010000001 (optional)

TK302 STD, TK303 STD, TK302 TF

Length	464 mm
Height	192.6 mm
Width	216 mm





NOTE: All the dimensions shown in figure are in millimetres and referred to devices with covers closed and without paper roll.



8.12 Power supply dimensions cod.963GE02000043 (optional)

Length	146.2 mm
Height	39 mm
Width	75.2 mm




NOTE:
All the dimensions shown in figures are in millimetres.

8.13 Paper specification

NOTE:
All the dimensions shown in following figures are in millimetres.

Paper with black mark

The following image shows the placement of the black mark on paper. The black mark can be printed both on the thermal side and on the non-thermal side of paper and it can be placed anywhere on the whole width of the paper. For more information about the use of paper with black mark see chapter 11.






Paper with barcode (for models with barcode reader)

The following image shows the placement of the barcode on the ticket. The barcode must be printed on the non-thermal side of the paper and at 25 mm from the edge of the ticket to ensure the correct barcode reading when ticket alignment is performed.

For more information about the use of paper with barcode see chapter 11.






Fan-fold paper with hole

(for KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, TK302 STD, TK303 STD)

The following image shows the placement of the hole on the paper. The hole can be positioned across the width of the ticket. To manage tickets with hole, set the parameter “Notch/B.Mark position” to “Transparent” (see par. 6.4). For more information about the use of paper with hole see chapter 11.






Fan-fold paper with hole

(for KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF)

The following image shows the placement of the hole on the paper. The hole can be positioned across the width of the ticket. To manage tickets with hole, set the parameter “Notch/B.Mark position” to “Transparent” (see par. 6.4). For more information about the use of paper with hole see chapter 11.

The hole must be positioned in a lateral position on ticket (see the following figures):

- for paper width = 82.5 mm, the hole may be positioned on the left and on the right side of the ticket
- for paper width = 54 mm or 60 mm, the hole may be positioned only on the right side of the ticket (next to the fixed paper guide).






Paper with labels

(for KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, TK302 STD, TK303 STD)

The following image shows a portion of paper with labels. To manage paper with label, you need to set a negative value for the parameter "Notch distance" (see par. 6.4).

For more information about the use of paper with hole see chapter 11.





Ticket with RFID tag (models with RFID reader/writer)


RFID (acronym for Radio Frequency IDentification) is a technology to identify automatically items using radio waves; this system is based on wireless data capture from RFID tag using appropriate readers. The RFID tag, or transponder, is made up of :


- the microchip that stores the data (including also a unique serial number written);
- an RFID antenna.

The device models equipped with RFID reader are equipped with an RFID transceiver, provided with antenna, that allows to send and receive RF data to and from the tag. For this application the ticket dimensions are not binding but for good reading is important that the tag inside the ticket, after alignment, intersects the antenna area.

The following figures show the available positions of antenna RFID inside the device

models with UHF RFID module




models with HF RFID module

NOTE: For ease of reference, for some models is represented only the printer group without external plastic chassis or triple feeder.



To use ticket with RFID tag with models with triple feeder, it is recommended to load ticket into the input feeder 2 (the central one), as shown in following figure.

The use of paper inputs 1 and 3 causes a slight bending of paper and therefore the integrity of TAG RFID is not guaranteed. Before proceeding, check with a sample ticket.





In CUSTOM/POS emulation, it is possible to use TrueType fonts. To be used, a TrueType font must be monospace type (every character of the font must have the same dimension). The check is made by the device when the font is selected. TrueType fonts will be automatically scaled by the device in order to obtain the same available width for the embedded fonts (11, 15 and 20 cpi for the 200dpi model and 16, 23 and 30 cpi for the 300dpi model).

The quality of TrueType fonts and the correct positioning into the printable area will result from the font producers and the font implementation.

For the correct printing of the code tables, it is necessary that the selected TrueType font contains all the characters in the tables. Otherwise, the '□' symbol will be printed instead the missing character.

All commands for printing configuration are usable both with TrueType fonts and with embedded fonts.

It is possible to address the TrueType font respects the UNICODE™ standard (see www.unicode.org), by using UTF-8 or UTF-16 encoding.



8.15 Character sets in SVELTA emulation

In SVELTA emulation the device has 20 embedded fonts of varying width which may be accessed through control characters (see commands description in SVELTA emulation of command manual). The following list shows the font available and relative dimensions in dot:

- | | |
|------------------------------------|--|
| • Font HEL8PT8 ^(A) | Proportional font with fixed height (H = 28 dot) |
| • Font HEL10PT8 ^(A) | Proportional font with fixed height (H = 34 dot) |
| • Font HEL14PT8 ^(A) | Proportional font with fixed height (H = 50 dot) |
| • Font HEL16PT8 ^(A) | Proportional font with fixed height (H = 55 dot) |
| • Font 18x24 | (Font 18x24 in CUSTOM/POS emulation) |
| • Font 14x24 | (Font 14x24 in CUSTOM/POS emulation) |
| • Font 10x24 | (Font 10x24 in CUSTOM/POS emulation) |
| • Font 8x12 ^(B) | Fixed font |
| • Font 8x12-2 ^(B) | Fixed font |
| • Font 12x12 ^(B) | Fixed font |
| • Font 14x11 ^(B) | Fixed font |
| • Font 16x24 ^(B) | Fixed font |
| • Font 16x24_1 ^{(B) (C)} | Fixed font |
| • Font 16x24_2 ^{(B) (C)} | Fixed font |
| • Font 20x15 ^(B) | Fixed font |
| • Font 28x20 ^(B) | Fixed font |
| • Font 14x24_1 ^{(B) (C)} | Fixed font |
| • Font 16x24CN ^{(B) (C)} | Fixed font |
| • Font OCRB (20x32) ^(B) | Fixed font |

For further information to characters representations print directly the font test ^(D).

In SVELTA emulation, it is possible to use TrueType fonts. True Type fonts are printable with every angle of rotation and in bold, reverse, italic and underlined mode.

It is possible to address the TrueType font respects the UNICODE™ standard (see www.unicode.org), by using UTF-8 or UTF-16 encoding.

For the correct printing of the code tables, it is necessary that the selected TrueType font contains all the characters in the tables. Otherwise, the '□' symbol will be printed instead the missing character.

NOTES:

- (A) : A proportional font is a font in which different characters have different pitches (widths).
- (B) : A fixed font is the opposite of a proportional font and is a fixed-pitch font.
- (C) : The fonts with the same name and dimension contain different characters in different positions from theirs.
- (D) : During power-up, if the FORM FEED (FF) key is held down, the device executes the FONT TEST.



9 CONSUMABLES



The following table shows the list of available consumables for device:

KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL

DESCRIPTION	CODE
THERMAL PAPER ROLL weight = 180 g/m ² width = 80 mm Ø external = 180 mm Ø core = 25 mm	67300000000386
THERMAL PAPER ROLL weight = 180 g/m ² width = 82.5 mm Ø external = 150 mm Ø core = 45 mm	67300000000409




TK302 STD, TK303 STD, TK302 TF

DESCRIPTION	CODE
<p>THERMAL FAN-FOLD MODULE (100 tickets)</p> <p>weight = 170 g/m² dimensions = 152 mm x 80 mm</p>	67A00000000308 
<p>THERMAL FAN-FOLD MODULE (100 tickets)</p> <p>weight = 140 g/m² dimensions = 152 mm x 80 mm</p>	67A00000000304 




10 ACCESSORIES

The following table shows the list of available accessories for device.

DESCRIPTION	CODE
KIT FOR HF RFID READER/WRITER (ELATEC) (for technical specifications, see paragraph 8.3)	918AV010400000
	918AV010200000

KIT FOR UHF RFID READER/WRITER (CAEN)
(for technical specifications, see paragraph 8.3)






KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL

DESCRIPTION	CODE
-------------	------


963GE020000043

POWER SUPPLY
(for technical specifications, see paragraphs 8.1 and 8.9)



974AU010000305

PAPER ROLL HOLDER
with cable length = 0.33 m
(see paragraphs 10.1)




KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL

DESCRIPTION	CODE
-------------	------





26300000000453

WIRINGS KIT WITH LOW PAPER SENSORS
length = 2 m
(see paragraph 10.2)





KPM302 STD, KPM303 STD

DESCRIPTION	CODE
EJECTOR DEVICE (for firmware release earlier than 3.28, a specific firmware upgrade is required for using this accessory)	976AU010000317 
SELECTOR DEVICE FOR HORIZONTAL FIXING (Specific firmware upgrade is required for using this accessory)	976AU010000318 
SELECTOR DEVICE FOR VERTICAL FIXING (Specific firmware upgrade is required for using this accessory)	976AU010000002 
CUT&HOLD KIT	976AV010000002 






TK302 STD. TK303 STD

DESCRIPTION	CODE
PAPER ROLL HOLDER	974BA010000001
KIT FOR HEIGHT REDUCTION (only for models with paper roll holder cod.974BA010000001)	976BB010000014
KIT FOR POWER SUPPLY CONTAINER (only for models with paper roll holder cod.974BA010000001)	976BB010000001



TK302 STD, TK303 STD, TK302 TF


DESCRIPTION	CODE
METAL TICKET TRAY	976BB010000003 
PLASTIC TICKET TRAY	976BD010000001 
KIT FOR BURSTER CONFIGURATION	976BA010000323 



10.1 Paper roll holder cod.974AU010000305 (optional)

For the device is available an external paper roll holder kit 974AU010000305 (supplied as an accessory). The kit makes it possible to use paper rolls with larger diameter (up to 150 mm).

The following figure shows the dimensions for holder support and paper roll pin (all the dimensions in figure are in millimetres).



NOTE:


For external rolls diameter higher to 100 mm it's recommended to use a paper pre-tensioning device.




10.2 Wirings kit with low paper sensor boards cod.26300000000453 (optional)

For the device is available a kit of wirings with low paper sensor boards 26300000000453 (supplied as an accessory). The kit makes it possible the connection between triple feeder and low paper sensors.

The kit includes three wirings assembled with three low paper sensors boards, as shown in following figure.



For the assembly procedure, proceed as follows:



Remove the cover for the triple feeder connectors by levering with a small slotted head screwdriver.

Connect the three wirings to the connectors of triple feeder.





11 ALIGNMENT

Device is provided with sensors for the use of alignment notch in order to handle:

- roll of tickets with pre-printed fields and a fixed length;
- fan-fold module of tickets with pre-printed fields and a fixed length.

The alignment notch may be formed by (see par.8.10):

- black mark printed on paper;
- hole between two tickets;
- gap between two labels (only for models without triple feeder).

All alignment sensors are “reflection” sensors: this kind of sensor emits a band of light and detects the quantity of light reflected to it.

The presence of the notch is therefore detected by the amount of light that returns to the sensor, considering that the light is reflected by the white paper and absorbed by the black mark.

To use tickets with holes or labels with gap, it is possible to use the same sensors as “transparence” sensors, coupled two by two: a beam of light is emitted by the transmitter sensor and the quantity of light which reaches the opposite receiver sensor is detected.

The presence of the hole/gap is detected evaluating the amount of light that arrives to the opposite sensor, considering that the paper doesn't allow the beam of light to reach the receiver, whereas a gap or a hole lets the light to reach the receiver.

The following paragraphs show how to correctly set the configuration parameters of device in order to assure the alignment.



11.1 Enable alignment


Device is provided with two sensors for alignment, placed as follows:

- one mobile sensor on the lower flat
- one mobile sensor on the upper flat.

To guarantee the alignment, it is necessary to correctly choose the sensor to use for the notch/b.mark detection depending on the type of notch/b.mark and its location on the ticket.

To do this, you must enable the parameter “Notch/B.Mark Position” during the setup procedure (see chapter 6) and set the correct value of this parameter as described in the following table.

SENSOR USED	VALUE OF THE “NOTCH/B.MARK POSITION” PARAMETER	USING MODE OF SENSORS	NOTCH TYPE
-	Disabled	-	Alignment disabled
1	Bottom	Reflection	Black mark printed on the non-thermal side of paper
2	Top	Reflection	Black mark printed on the thermal side of paper
1 + 2	Transparent	Transparency	Hole between tickets or gap between labels




NOTE: For ease of understanding, image shows the two flats represented in the same plane.

For ease of reference, for some models is represented only the internal printer group without external plastic chassis or triple feeder.


The following figures show the usable format of paper and the corresponding sensors used for alignment:

Paper with black mark on the non-thermal side






Paper with black mark on the thermal side






Tickets with hole





Paper with labels

(for KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, TK302 STD, TK303 STD)





11.2 Calibration

The sensor calibration occurs automatically and consists in adjusting the quantity of light emitted to match the degree of whiteness of the paper used and the degree of black of the mark printed on paper.

The device automatically performs the self-calibration during the setup procedure only if the “Notch/B.Mark Position” parameter is set to a value other than “Disabled” (see chapter 6).

Otherwise, the self-calibration can be started manually by pressing the S1 key during power-up.

When self-calibration starts, the device performs some paper feeds and then it prints the calibration result and the value of the PWM duty-cycle of the alignment sensor driver so that it can perform an optimal notch detection:

Autosetting Notch : OK
PWM Duty Cycle : 85.3%


The “Autosetting Notch” parameter indicates the result of the self-calibration procedure; OK will appear if it has been successful, NOT OK will appear if the procedure has failed.

After the printing of the procedure result, the device offers the execution of the function of paper characterization “Characterize Paper” and the change of the “Notch/B.Mark Threshold” parameter which represents the detection threshold of the notch. Choosing the “Yes” value for the “Characterize Paper” parameter, the device prints a graphic representation (see following figures) of the outgoing voltage of the alignment sensor (expressed as a percentage) and the “Notch/B.Mark Threshold” value.

This graphic representation is useful to set the most suitable value to assign to the “Notch/B.Mark Threshold” parameter and then to better identify the optimal threshold value which takes into account the variations of the signal and the small oscillations around zero.

The following figure shows an example of paper with the non-thermal paper printed with black marks: the outgoing voltage is constant while passing the white paper between two black marks and presents a peak at each black mark.


In this case, the optimal value for the “Notch/B.Mark Threshold” parameter is placed about half of the peak (as shown in figure).





The following figure shows an example of paper with holes: the outgoing voltage is constant while passing the paper between two holes and presents a variation at each hole.


In this case, the optimal value for the "Notch/B.Mark Threshold" parameter is placed about half of the variation.





The following figure shows an example of paper with the non-thermal paper printed with black marks and other graphics (for example, a barcode): the outgoing voltage is constant while passing the white paper between two black marks, presents a peak at each black mark and presents some "noise" at each barcode.

In this case, the optimal value for the "Notch/B.Mark Threshold" parameter is located about halfway between the peak value and the maximum value of the "noise" (as shown in figure):



If the maximum value of "noise" read by the sensor is very close to the peak value, it might be difficult to place the value of the "Notch/B.Mark Threshold" at an intermediate point. In these cases, it is mandatory that the portion of paper between the point of printing end and the front notch is completely white (no graphics). In this way, the only next graphic detected by the sensor for alignment after the printing end will be the notch.




11.3 Alignment parameters


The “alignment point” is defined as the position inside the ticket to use for the notch/b.mark alignment. The distance between the notch/b.mark edge and the alignment point is defined as “Notch Distance”.

The value of “Notch Distance” varies from a minimum value of -5 mm to a maximum value of 66 mm.

If the “Notch Distance” value is set to 0, the alignment point is set at the beginning of the notch/b.mark:




The following figure shows an example of paper with alignment point set by a positive value of “Notch Distance” (“Notch Distance” = + A):






To set a negative value of the “Notch Distance” parameter is useful in cases where the alignment point refers to the notch/b.mark on the previous ticket or where the desired cutting line is placed in the middle of the alignment notch/b.mark (for example, for paper with holes or gap). In the following images, the value of “Notch Distance” parameter is set to -A.





The following figure shows a simplified section of the device with the paper path and the distances (in millimetres) between the alignment sensors, the printing head and the cutter (cutting line).





CUSTOM/POS emulation

To define the alignment point you need to set the printer parameters that compose the numerical value of the "Notch Distance" parameter (see par. 6.4).

For example, to set a notch distance of 15 mm between the notch/b.mark and the alignment point, the parameters must be set on the following values:

<i>Notch Distance Sign</i>	:	+
<i>Notch Distance [mm x 10]</i>	:	1
<i>Notch Distance [mm x 1]</i>	:	5
<i>Notch Distance [mm x .1]</i>	:	0

The "Notch Distance" parameter, may be modified as follows:

- during the setup procedure of the device (see chapter 6)
- by modifying the Setup.ini file (see par.13.9)
- by using the command 0x1D 0xE7 (for more details, refer to the commands manual)
- by driver.


SVELTA emulation

The ticket features and the alignment parameters, may be modified as follows:

- by using the parameters of the <LHT> command (for more details, refer to the commands manual)
- by modifying the Setup.ini file (see par.13.9)
- by driver

The following figure shows some of the parameters for alignment of the Setup.ini file:

- "Ticket X Dimension"
- "Ticket Y Dimension"
- "Notch Width"
- "Notch Distance"






11.4 Printing area

In order to print ticket containing only one notch/b.mark and to not overlay printing to a notch/b.mark (that will make it useless for the next alignment), it is important to well calibrate:

- the length of the printing area of ticket according to the inter-notch distance;
- the value for the paper recovery after a cut.

The following figure shows an example of tickets with “Notch Distance” set to 0:



A “Non-printable area” generated from:

“Distance between cutter/printing head”- “Value for the paper recovery after a cut”

where:

“Distance between cutter/printing head” = 24 mm (fixed distance)

“Value for the paper recovery after a cut”= 9 mm (in CUSTOM/POS emulation)

24 mm (in SVELTA emulation)

In CUSTOM/POS emulation, after a performed cut, the paper is not completely recovered (in order to avoid jamming when using of thin paper). Otherwise, in this emulation you can use the command 0x1C 0xC1 to modify the “Value for the paper recovery after a cut” (see commands manual).

The SVELTA emulation, instead, it is designed specifically for ticketing and then for using with heavy paper, which avoids the risk of paper jams. After performing a cut, the device completely recovers the paper

H Distance between the first and the last print line, called “Height of the printing area”.

L Distance between an edge of the notch and the next one, called “Inter-notch distance”.

D Automatic feed for alignment at the next notch.

To use all the notches on paper, you must comply with the following equation:

$$H + A \leq L$$

The height of the printing area (H) can be increased to make no progress on alignment (D) but no further.



12 TECHNICAL SERVICE

In case of failure, send the 4 pieces of information listed below to our support team:

1. Product code
2. Serial number
3. Hardware release
4. Firmware release

To get the necessary data, proceed as follows:

1

XXXXXXXXXXXXXX Rx



00000000000000000000

Write down the data printed on the product label (see paragraph 3.5).

2

<device name>

SCODE: <code>	- rel 1.00
BCODE: <code>	- rel 1.00
FCODE: <code>	- rel 1.00
UCODE: <code>	- rel 1.00
DCODE: <code>	- rel 1.00
CPLD	- rel 1.00

FW

PRINTER SETTINGS

PRINTER TYPE	<device model>
Barcode Reader	Not Present
RFID module	Not Present
PRINTING HEAD TYPE	<head model>
INTERFACE	RS232
ETHERNET TYPE	10/100Base-TX
PROGRAM MEMORY TEST.....	OK
DYNAMIC RAM TEST.....	OK
EEPROM TEST.....	OK
CUTTER TEST.....	OK
PRINTER HEAD Rav	561

Print a setup report (see paragraph 6.1)
The setup report shows
the firmware release.







13 ADVANCED FUNCTIONS


13.1 File sharing

The device can be connected to a PC through two types of connections (see par. 4.5):

1. with USB cable
2. with Ethernet cable.

According to the connection made, it is possible to manage drivers, fonts and logos of the device and configure the operating parameters in three different ways

1. by files sharing from Mass Storage, in case of USB connection
2. by files sharing from FTP Server connection, in case of Ethernet connection
3. by entering the Embedded Web Server, in case of Ethernet connection.





13.2 Embedded Web Server

The device is equipped with an Embedded Web Server that allows to execute some operations on devices, through a clear web interface, including:

- monitoring the printer status;
- setting operating parameters;
- configuring network settings;
- managing the logos;
- configuring the email service to make diagnostics and maintenance operations easier;
- download printing drivers.

Before entering in the Embedded Web Server, check that:

- the device is connected and turned on;
- the device has a network connection based on the IP protocol;
- the following ports are opened (if a Firewall is present on computer): 9100 (or differently set up). 15000, 15001, 15002;
- have a Web browser on the computer;
- the device is connected to the network and its IP address and its Subnet Mask are set up in a correct way. To check the setting of these parameters, open a new terminal window and type “ping” on the command bar followed by the IP address of the device. The picture shows an example of a positive result after the “ping” command. Otherwise, if connection isn’t possible, to its IP address, a failure notice will appear.

Example: ping 192.168.10.37

```
Command Prompt X
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\>ping 192.168.10.37

Pinging 192.168.10.37 with 32 bytes of data:

Replay from 192.168.10.37: bytes=32 time<1ms TTL=64

Ping statistics for 192.168.10.37:
    Packets: sent = 4, Received = 4, Lost = 0 (0% loss.),
Approximate round trip times in milli-seconds:
    minimum = 0ms, Maximum = 0ms, Average = 0ms

c:\>
```




13.3 Embedded Web Server : access

To enter the Embedded Web Server, type the IP address assigned to the device into Web browser. To know the IP address of the device, print the Set-up report of the device (see chapter 6) or use the software LOCATOR. For example, if IP address of the device is 192.168.10.37, type in the Web browser:

http://192.168.10.37

On the screen will appear the internal default page that corresponds to the section “Device Info” The home page is divided into 6 areas whose functions are described below:

- | | |
|----------------------------|--|
| 1. SECTIONS: | The web server has three sections listed within each web page. These sections are: Device Info, Printer Settings, Printer Support. |
| 2. CURRENT PAGE | Reports section currently displayed. |
| 3. TOOLS | Lists the tools available within the chosen section. |
| 4. PRINTER PICTURE | Displays a picture representative of the device operational status. The picture changes depending on the parameters reported in area number 5. |
| 5. REAL TIME STATUS | Report a list of operating parameters controlled and monitored in real time (with a regular refresh from 5 to 15 seconds). |
| 6. TIME AND DATE | Displays the current time and date. |





To enter some sections and some configuration services, it is required the identification of the user and password. To make registration and to obtain the access to the restricted areas, when it is required insert the user name and the password as indicated in the following table:

User Name	Custom
Password	AlwaysOn

NOTE:

Respect capital and small letters as indicated in table.



13.4 Embedded Web Server: functions

The “Printer Settings” section is a restricted one. To enter the section, it is required the identification of the user and password. With the tools of this section, it is possible to set up the same parameters of the device that are configurable in the setup mode (see chapter 6).

The following figure shows the page for the “EMAIL SETUP” tool. It is divided into 4 areas:

- 1. SECTIONS:** The web server has three sections listed within each web page. These sections are: Device Info, Printer Settings, Printer Support.
- 2. CURRENT PAGE** Reports section currently displayed.
- 3. TOOLS** Lists the tools available within the chosen section.
- 4. EMAIL SETUP** Displays the fields available to configure the automatically delivery of service email in order to inform the user when a change occurs to operating status of the device. It is possible to select the events to enable the sending of the email

1 DEVICE INFO | PRINTER SETTINGS | PRINTER SUPPORT

2 < Device name >

3

4

E-Mail Service Settings	
SMTP Server Address	smtp.xxxxxx.it
SMTP Server Port	25
E-mail To	Utente@xxxxxx.it
E-mail From	<PRINTER>@xxxxxx.it
E-mail Subject	test
E-mail Message	
Testo libero	
<input checked="" type="checkbox"/> Include Printer Status	
<input type="checkbox"/> when Paper End is detected <input type="checkbox"/> when Near Paper End is detected <input checked="" type="checkbox"/> on Printer Power On <input checked="" type="checkbox"/> when Near Paper End is detected <input type="checkbox"/> on Cut <input type="checkbox"/> on LF key pressed <input type="checkbox"/> on FF key pressed <input type="checkbox"/> on S1 key pressed <input type="checkbox"/> on S2 key pressed <input checked="" type="checkbox"/> on Cut error <input checked="" type="checkbox"/> on Paper Jam <input checked="" type="checkbox"/> on Notch Align error <input type="checkbox"/> on Autoload <input checked="" type="checkbox"/> on Head Over Temperature error <input checked="" type="checkbox"/> on Supply Voltage error	
<input type="button" value="Reset e-mail settings..."/> <input type="button" value="Save e-mail settings"/>	



With the tools in the “Printer Support” section, it is possible to download drivers, manage logos and test some device functions for demonstrative and service purpose.

The following figure shows the page for the “ADVANCED FUNCTIONS” tool. It is divided into 4 areas:

- 1. SECTIONS:** The web server has three sections listed within each web page. These sections are: Device Info, Printer Settings, Printer Support.
- 2. CURRENT PAGE** Reports section currently displayed.
- 3. TOOLS** Lists the tools available within the chosen section.
- 4. ADVANCED FUNCTION** Displays all the tests available for the device: printing a test page, the font test and the logos test, the self-calibration of the notch sensors and the ticket alignment.

The screenshot shows the "Advanced Function" page of a printer's web interface. The page is titled "< Device name >". At the top, there are three navigation links: "DEVICE INFO", "PRINTER SETTINGS", and "PRINTER SUPPORT". A sidebar on the left contains links for "Web Site", "PRINTER SUPPORT" (which is highlighted in black), "Download Driver", "Advanced Function", "Picture Settings", "Font Settings", and "Firmware Upgrade". The main content area is divided into several sections: "Advanced Function", "Test Page" (with "Print Test Page" and "Exec Test Page" buttons), "Logo Test" (with "Logo Description" dropdown and "Print all Logos" checkbox), "Font Test" (with "Font Description" dropdown set to "CUSTOM/POS - 11 CPI" and "Exec Font Test" button), and "Advanced Function" (with buttons for "Notch Autoset", "Characterize Paper", "Align ticket to print", "Align ticket to cutter", "Cut Paper", and "Reset To Factory Default").

1 → DEVICE INFO | PRINTER SETTINGS | PRINTER SUPPORT

2 → PRINTER SUPPORT

3 → Advanced Function

Warning : Use these function only when the printer is in standby!
All functions below, if used while the printer is executing a print job from communication port, may corrupt the printout.

Print Test Page	Test Page Exec Test Page
Logo Description	Logo Test <input type="checkbox"/> Print all Logos
Logo Test	Exec Logo Test
Font Description	Font Test CUSTOM/POS - 11 CPI
Font Test	Exec Font Test
Notch Autoset	Advanced Function Exec Notch Autoset
Characterize Paper	Exec Paper Characterization
Align ticket to print	Exec Align
Align ticket to cutter	Exec Align to cut
Cut Paper	Exec Paper Cut
Reset To Factory Default	Reset To Factory Default

4 →




13.5 Locator

With the devices it is possible to use an external software to perform a search for devices connected to the network with Ethernet cable, even without knowing the IP addresses of individual devices.

The following figure shows the software interface:

1. **DEVICES:** Displays the list of the connected devices.
2. **“START...”** Starts a new search.
3. **“CONF.”** Enters the configuration window of the network parameters of the selected devices.





13.6 Drivers installation

Embedded Web Server

To install a new driver update for the device, enter the “DRIVER” page of the “PRINTER SUPPORT” section of the embedded Web Server (see the following figure).

The screenshot shows the Embedded Web Server interface. On the left, there's a sidebar with "Web Site" at the top, followed by a dark bar labeled "PRINTER SUPPORT" which contains links for "Download Driver", "Advanced Function", "Picture Settings", "Font Settings", and "Firmware Upgrade". The main content area has a header with "DEVICE INFO", "PRINTER SETTINGS", and "PRINTER SUPPORT". Below this is a graphic of a printer with the text "<PRINTER>". The main title is "< Device name >". Under "Download Driver", it says "You can find on this section the printer drivers. The drivers are stored inside the printer memory: is not needed an active internet connection". It lists two download options: "Microsoft Windows GPD Driver" (file: <Printer>_rel_111_Win2K_2K3_XP.exe, Release: 1.11, File Size: 37 KB) and "CUPS (Common Unix Printer System) based printer drivers" (file: <Printer>_cupsdrv-1.00.tar.gz, Release: 1.00, File Size: 12 KB). Each download link has a "Download file >>" button to its right.

Mass Storage / FTP Server

It is possible to install the new driver update directly into the folder “DRIVER” on the Flash Drive of the device. You can enter the Flash Drive by files sharing from Mass Storage or by files sharing from FTP Server connection (see par.13.1). In both cases, the relative parameter should be enabled during the configuration process (see chapter 6).

NOTE: To know the IP address of the device, print the setup report of the device (see chapter 6) or use software LOCATOR. Type in the address bar “ftp://” followed by the IP address of the device.



13.7 Logos management

It is possible to store new logos in addition to default logos stored on Flash Disk. The device automatically provides to convert BMP image to the error-diffusion format in black and white.

Logos may be stored both on Flash Disk and on the SD/MMC card.

The use of the SD/MMC card allows to handle more logos (however, the max number of manageable logos is limited by the RAM memory reserved for logos management).

Embedded Web Server

To add a new logo to the device enter the “PICTURE SETTINGS” page of the “PRINTER SUPPORT” section of the embedded Web Server (see the following figure).

The screenshot shows the "Printer Support" section of the Embedded Web Server. The left sidebar has a "Web Site" link and a "PRINTER SUPPORT" menu with options: Download Driver, Advanced Function, Picture Settings (selected), Font Settings, and Firmware Upgrade. The main content area has tabs: DEVICE INFO, PRINTER SETTINGS, and PRINTER SUPPORT. The PRINTER SUPPORT tab is active, showing a printer icon and the placeholder text "< Device name >". Below this is the "Picture Settings" section. A warning message states: "Warning : Use these function only when the printer is in standby! All functions below, if used while the printer is executing a print job from communication port, may corrupt the printout." The "Add New Logo" form includes fields for Picture to Add (with a "Sfoglia..." browse button), Logo Number, Logo Destination (set to Flash Disk with a checked checkbox), and Send Test (with a "Add New Logo" button). Below this is a "File System Free Space" table showing "Flash Drive" with 1.02 Mb free and "Memory Card" with "Disk Not Found". The "Logo Test" section includes a "Logo Description" dropdown set to "1 - Pict1.bmp" with a checked checkbox, and a "Print all Logos" checkbox. It also has an "Exec Logo Test" button. The final section is "Delete Logo" with a "Delete Selected Logo" button. The bottom right corner of the window has scroll bars.



Mass Storage / Server FTP

It is possible to add the new logo directly into the folder “PICTURES” on the Flash Drive of the device. You can enter the Flash Drive by files sharing from Mass Storage or by files sharing from FTP Server connection (see par. 13.1).

In both cases, the relative parameter should be enabled during the configuration process (see chapter 6).

After adding the logo, open the configuration file “PictList.ini” and add a new line with a number associated to the logo (to be used with device’s commands), a letter for the memory unit and the logo file name, as indicated in the instructions written inside the “PictList.ini” file.

To delete a logo stored in the device, proceed as follows:

1. delete the selected logo from the “Pictures” folder on Flash Disk or SD/MMC card;
2. in the configuration file “PictList.ini”, delete the line related to the erased logo.

The logos stored into the Flash Drive or the SD/MMC card and converted by the device, can be printed by using the number associated to the logo during the conversion step.

The correspondence between file-name and logo-number is warrant by the configuration file “PictList.ini” and it is verifiable with the logo test.

NOTE: To know the IP address of the device, print the setup report of the device (see chapter 6) or use software LOCATOR. Type in the address bar “ftp://” followed by the IP address of the device.

ATTENTION:

The configuration file “PictList.ini” on the device’s Flash Disk, has to be modified even if the new added logo is stored on the SD/MMC card.



13.8 Fonts management

It is possible to store new font in addition to default fonts stored on Flash Disk.

Fonts may be stored on Flash Disk both on Flash Disk and on the SD/MMC card.

The use of the SD/MMC card allows to handle more fonts (however, the max number of manageable fonts is limited by the RAM memory reserved for fonts management).

Embedded Web Server

To add a new font to the device enter the “FONT SETTINGS” page of the “PRINTER SUPPORT” section of the embedded Web Server (see the following figure).

The screenshot shows the "Font Settings" page of the "PRINTER SUPPORT" section of the Embedded Web Server. The top navigation bar includes "DEVICE INFO", "PRINTER SETTINGS", and "PRINTER SUPPORT". The main header is "< Device name >". On the left, a sidebar lists "Web Site", "PRINTER SUPPORT" (selected), "Download Driver", "Advanced Function", "Picture Settings", "Font Settings" (selected), and "Firmware Upgrade". The "Font Settings" section contains a warning about using functions in standby mode. It features three main sections: "Add New Font" (with a file selection field and "Sfoglia..." button), "Font Destination" (with a dropdown menu), and "Send Font" (with a "Add New Font" button). Below these is a "File System Free Space" section showing "Flash Drive" (Free 1.02 Mb) and "Memory Card" (Disk Not Found). The "Font Test" section includes "Font Description" (Vera.ttf, CUSTOM/POS - 11 cpi checked, Flash Disk), "Font Test" buttons ("Exec Font Test" and "Print Embedded Font Charmap"), and a "Delete Existing Font" section with "Font Description" (Vera.ttf, Flash Disk) and a "Delete Font" button ("Delete Selected Font").



Mass Storage / Server FTP

It is possible to add the new font directly into the folder “FONTS” on the Flash Drive of the device. You can enter the Flash Drive by files sharing from Mass Storage or by files sharing from FTP Server connection (see par. 13.1).

In both cases, the relative parameter should be enabled during the configuration process (see chapter 6).

NOTES:

To know the IP address of the device, print the setup report of the device (see chapter 6) or use software LOCATOR. Type in the address bar “ftp://” followed by the IP address of the device.

Uploading the new font directly from the “Font” folder of Microsoft® Windows® directory, remember that the displayed font name into the “Font” folder may not match the real name of the font file.




13.9 Setup

Embedded Web Server

Device permits the configuration of default parameters for device and network setup by entering the “PRINTER SETUP” page and the “NETWORK SETUP” page of the “PRINTER SETTINGS” section of the embedded Web Server (see the following figure).

Web Site
DEVICE INFO | PRINTER SETTINGS | PRINTER SUPPORT


< Device name >

PRINTER SETTINGS

- [Printer Setup](#)
- [Network Setup](#)
- [Email Setup](#)
- [Email Log](#)

< PRINTER > Printer Settings						
Printer Emulation	CUSTOM/POS <input checked="" type="checkbox"/>					
Autofeed	CR disabled <input type="checkbox"/>					
Chars/inch	A=15 B=20 cpi <input type="checkbox"/>					
Busy Condition	RxFull <input checked="" type="checkbox"/>					
Print Mode	Normal <input type="checkbox"/>					
Print Density	0% <input type="checkbox"/>					
Speed/Quality	High Speed <input type="checkbox"/>					
Paper Width	82 mm <input type="checkbox"/>					
Paper Threshold	40 % <input type="checkbox"/>					
Notch Position	Disabled <input type="checkbox"/>					
Notch Threshold	40 % <input type="checkbox"/>					
Notch Distance	+0.0 <input type="text"/>					
Ticket Locking	Disabled <input type="checkbox"/>					
Paper End Buffer Clear	Disabled <input type="checkbox"/>					
COM Port Settings						
RS232 Baud Rate	115200 bps <input type="checkbox"/>					
RS202 Data Length	8 bits/chr <input type="checkbox"/>					

? January, 2015

<<
<
Today
>
>>

wk	Sun	Mon	Tue	Wed	Thu	Fri	Sat
16							1
17	2	3	4	5	6	7	8
18	9	10	11	12	13	14	15
19	16	17	18	19	20	21	22
20	23	24	25	26	27	28	29
21	30	31					

Time: Select date Apply Date and Time



Mass Storage / FTP Server

It is possible to configure the default parameters for device and network setup by editing the "Setup.ini" file on the device Flash Drive.

You can enter the Flash Drive by files sharing from Mass Storage or by files sharing from FTP Server connection (see par.13.1).

In both cases, the relative parameter should be enabled during the configuration process (see chapter 6).

After editing device's parameter, simply save the "Setup.ini" file to make the modifies activated.

The "Setup.ini" file is a configuration file that contains all the configurable parameters listed in text format and divided into some sections (indicated in square brackets).

The available values for every parameter, are listed after the parameter name. The value marked with the symbol ' * ' is the default one.

To modify device's parameters, change the numeric value after the name of parameters. To set the parameter to the default value, change the numeric value with the symbol D.

The "Setup.ini" file permits the configuration of the following parameters:

[PRINT]

Printer Emulation	0, 1*	0 = CUSTOM/POS 1 = SVELTA
Print Mode	0*, 1	0 = Normal 1 = Reverse
Autofeed	0*, 1	0 = CR disabled 1 = CR enable
Chars / inch		
KPM302 STD, KPM302 EJ, KPM302 vSEL KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 STD TK302 TF	0, 1*	0 = A=11 B=15 cpi 1 = A=15 B=20 cpi
KPM303 STD, KPM303 EJ, KPM303 vSEL, TK303 STD	0, 1*	0 = A=16 B=23 cpi 1 = A=23 B=30 cpi
Speed / Quality	0, 1, 2*	0 = High Quality 1 = Normal 2 = High Speed



Paper Width	0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14*, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31	0 = 54 mm 1 = 56 mm 2 = 58 mm 3 = 60 mm 4 = 62 mm 5 = 64 mm 6 = 66 mm 7 = 68 mm 8 = 70 mm 9 = 72 mm 10 = 74 mm	11 = 76 mm 12 = 78 mm 13 = 80 mm 14 = 82 mm 15 = 20mm 16 = 22 mm 17 = 24 mm 18 = 26 mm 19 = 28 mm 20 = 30 mm 21 = 32 mm	22 = 34 mm 23 = 36 mm 24 = 38 mm 25 = 40 mm 26 = 42 mm 27 = 44 mm 28 = 46 mm 29 = 48 mm 30 = 50 mm 31 = 52 mm
Paper Threshold	0, 1*, 2, 3, 4, 5, 6	0 = 30 % 1 = 40 % 2 = 50 %	3 = 60 % 4 = 70 % 5 = 80 %	6 = 90 %
Notch/B.Mark Position	0*, 1, 2, 3	0 = Disabled 1 = Bottom	2 = Top 3 = Trasparent	
Notch/B.Mark Threshold	0, 1, 2, 3*, 4, 5, 6	0 = 30 % 1 = 40 % 2 = 50 %	3 = 60 % 4 = 70 % 5 = 80 %	6 = 90 %
Notch Distance [mm]				
Notch/B.Mark Min.Width	0*, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20	0 = 0 mm 1 = 1 mm 2 = 2 mm 3 = 3 mm 4 = 4 mm 5 = 5 mm 6 = 6 mm 7 = 7 mm	8 = 8 mm 9 = 9 mm 10 = 10 mm 11 = 11 mm 12 = 12 mm 13 = 13 mm 14 = 14 mm 15 = 15 mm	16 = 16 mm 17 = 17 mm 18 = 18 mm 19 = 19 mm 20 = 20 mm
PaperEnd Buffer Clear	0*, 1	0 = Disabled 1 = Enabled		
Ticket Locking				
KPM302 STD, KPM303 STD, KPM302 EJ, KPM303 EJ, KPM302 vSEL, KPM303 vSEL, TK302 STD, TK303 STD	0*, 1	0 = Disabled 1 = Enabled		
KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF	0*, 1, 2, 3	0 = Disabled 1 = By Printer	2 = By Feeder 3 = Complete	
Ticket Management	0*, 1, 2, 3	0 = Disabled 1 = Short Ticket	2 = Check First 3 = Stub+Ticket	



PaperEnd Management (KPM302 TF, KPM302 TF-EJ, KPM302 TF-vSEL, KPM302 TF-hSEL, TK302 TF)	0*, 1, 2	0 = Print All 1 = Eject	2 = Retract
Print Density	0, 1, 2, 3, 4*, 5, 6, 7, 8	0 = - 50 % 1 = - 37 % 2 = - 25 %	3 = - 12 % 4 = 0 % 5 = + 12 % 6 = + 25 % 7 = + 37 % 8 = + 50 %

[INTERFACE]

RS232 Baud Rate	1, 2, 3, 4, 5, 6, 7, 8*	1 = 1200 bps 2 = 2400 bps 3 = 4800 bps	4 = 9600 bps 5 = 19200 bps 6 = 38400 bps	7 = 57600 bps 8 = 115200 bps
RS232 Data Length	0*, 1	0 = 8 bits/chr 1 = 7 bits/chr		
RS232 Parity	0*, 1, 2	0 = None 1 = Even	2 = Odd	
RS232 Handshaking	0*, 1	0 = Xon/Xoff 1 = Hardware		
Busy Condition	0*, 1	0 = RxFull 1 = OffLine/RxFull		
USB Mass Storage	0*, 1	0 = Disabled 1 = Enabled		
USB Address Number	0*, 1, 2, 3, 4, 5, 6, 7, 8, 9	0 = 0 1 = 1 2 = 2 3 = 3	4 = 4 5 = 5 6 = 6 7 = 7	8 = 8 9 = 9
RFID Module Baud Rate	0*, 1, 2, 3, 4, 5, 6, 7, 8	1 = 38400 bps 2 = 57600 bps 3 = 115200 bps	4 = 1200 bps 5 = 2400 bps 6 = 4800 bps	7 = 9600 bps 8 = 19200 bps



[SVELTA]

Ticket X Dimension

Ticket Y Dimension

Notch/B.Mark Distance

Notch/B.Mark Width

Barcode Timeout

Ticket Offset X

Ticket Offset Y

[NETWORK]

DHCP Client 0*, 1 0 = Disabled
 1 = Enabled

FTP Server 0*, 1 0 = Disabled
 1 = Enabled

IP Address

Subnet Mask

Default Gateway

Domain Name System

TCP Printer Port

MAC Address (read only)

NOTA:

To know the IP address of the device, print the Set-up report of the device (see chapter 6) or use "Locator". Type in the address bar "ftp://" followed by the IP address of the device.



CUSTOM®

CUSTOM S.p.A.

World Headquarters

Via Berettine, 2/B - 43010 Fontevivo, Parma ITALY

Tel. +39 0521 680111 - Fax +39 0521 610701

info@custom.biz - www.custom.biz

All rights reserved

www.custom.biz